# FRIGIDAIRE.



# SINGLE WALL OVEN WSe & Care

Introduction	Settir
Important Safety Instructions 3	Care
Cooking Recommendations 9	Befor
Before Setting Oven Controls 14	Warra

Setting Oven Controls 20	0
Care and Cleaning 4	7
Before You Call 5	3
Warranty	6

A22383501/B (Oct 2021)

# Welcome to our family

Thank you for bringing Frigidaire into your home! We see your purchase as the beginning of a long relationship together.

This manual is your resource for the use and care of your product. Please read it before using your appliance. Keep it handy for quick reference. If something doesn't seem right, the troubleshooting section will help you with common issues.

FAQs, helpful tips and videos, cleaning products, and kitchen and home accessories are available at www. frigidaire.com.

We are here for you! Visit our website, chat with an agent, or call us if you need help. We may be able to help you avoid a service visit. If you do need service, we can get that started for you.


Let's make it official! Be sure to register your product.

Keep your product info here so it's easy to find.

Model Number:	

Serial Number:

Purchase Date: \_\_\_\_



**Serial Number Location** 

# **V**

#### **Installation Checklist**

- Read all the safety instructions in the front of your Use & Care Manual.
- Remove all packaging materials from your appliance before cooking.
- Confirm that the electrical power to the appliance is turned on.
- Wipe out the inside of the oven cavity with a damp cloth.
- Apply a thin layer of cooking oil to the sides of the oven racks to keep them gliding smoothly.
- Set the clock. See (page 16) for instructions.
- Before cooking, set the oven to bake at 350°F (177°C) for 30 minutes (page ref). Some noise and odors are normal on the first cooking cycle.
- Remember to complete your product registration!

Read all instructions before using this ap-

This manual contains important safety symbols and instructions. Please pay attention to these symbols and follow all instructions given.

Do not attempt to install or operate your appliance until you have read the safety precautions in this manual. Safety items throughout this manual are labeled with a WARNING or CAUTION statement based on the risk type.

Warnings and important instructions appearing in this guide are not meant to cover all possible conditions and situations that may occur. Common sense, caution, and care must be exercised with installing, maintaining, or operating your appliance.

#### **DEFINITIONS**

• This is the safety alert symbol. It is used to alert of potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.



#### WARNING

Indicates a potentially hazardous situation which, if not avoided, may result in death or serious injury.



#### CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



#### IMPORTANT

Indicates installation, operation or maintenance information which is important but not hazard-related.



#### NOTE

Indicates a short, informal reference something written down to assist the memory or for future reference.




# WARNING



## **Tip Over Hazard**

- A child or adult can tip the oven and be killed.
- Install the anti-tip device to oven and/or structure per installation instructions.
- Ensure the anti-tip device is re-engaged when the oven is moved.
- Do not operate the oven without the anti-tip device in place and engaged.
- Failure to follow these instructions can result in death or serious burns to children and adults.



Refer to the installation instructions supplied with your appliance for proper installation.

# Anti-tip mounting holes

Check for proper installation with a visual check that the anti-tip screws are present. Test the installation with light downward pressure on the open oven door. The oven should not tip forward.

## IMPORTANT SAFETY INSTRUCTIONS

#### IMPORTANT INSTRUCTIONS FOR UNPACKING AND INSTALLATION

# **■** IMPORTANT

Read and follow the below instructions and precautions for unpacking, installing, and servicing your appliance.

Remove all tape and packaging before using the appliance. Destroy the carton and plastic bags after unpacking the appliance. Never allow children to play with packaging material. Do not remove the wiring label and other literature attached to the appliance. Do not remove model/serial number plate.

Cold temperatures can damage the electronic control. When using this appliance for the first time, or when the appliance has not been used for an extended period of time, be sure the appliance has been in temperatures above 32°F (0°C) for at least 3 hours before turning on the power to the appliance.

All materials used in construction of cabinets, enclosures, and supports surrounding the product must have a temperature rating above 194°F (90°C).

Never modify or alter the construction of the appliance by removing the leveling legs, panels, wire covers, anti-tip brackets/ screws, or any other part of the appliance.

Be sure to have an appropriate foam-type fire extinguisher available, visible, and easily accessible located near the appliance.

#### GROUNDING INSTRUCTIONS



## WARNING

- Avoid fire hazard or electrical shock. Failure to follow this warning may cause serious injury, fire, or death.
- Avoid fire hazard or electrical shock. Do not use an adapter plug, use an extension cord, or remove grounding prong from the power cord. Failure to follow this warning may cause serious injury, fire, or death.

Proper Installation—Be sure your appliance is properly installed and grounded by a qualified technician. In the United States, install in accordance with the National Fuel Gas Code ANSI Z223.1/NPFA No. 54. latest edition and National Electrical Code NFPA No. 70 latest edition, and local electrical code requirements. In Canada, install in accordance with CAN/CGA B149.1 and CAN/CGA B149.2 and CSA Standard C22.1. Canadian Electrical code, Part 1-latest editions and local electrical code requirements. Install only per installation instructions provided in the literature package for this appliance.

For personal safety, this appliance must be properly grounded. For maximum safety, the power cord must be securely connected to an electrical outlet or junction box that is the correct voltage, is correctly polarized and properly grounded, and protected by a circuit breaker in accordance with local codes.

It is the personal responsibility of the consumer to have the appropriate outlet or junction box with the correct, properly grounded wall receptacle installed by a qualified electrician. It is the responsibility and obligation of the consumer to contact a qualified installer to assure that the electrical installation is adequate and is in conformance with all local codes and ordinances.

#### IMPORTANT INSTRUCTIONS FOR USING THE APPLIANCE

#### WARNING

- Storage In or On Appliance—Flammable materials should not be stored in an oven or microwave, near surface burners or elements, or in the storage or warmer drawer (if equipped). This includes paper, plastic, and cloth items, such as cookbooks, plastic ware, and towels, as well as flammable liquids. Do not store explosives, such as aerosol cans, on or near the appliance.
- Do not leave children alone Children should not be left alone or unattended in the area where appliance is in use. They should never be allowed to sit or stand on any part of the appliance, including the storage drawer, lower broiler drawer, warmer drawer, or lower double oven.
- Do not store items of interest to children in the cabinets above the appliance or on the backguards of ranges. Children climbing on or near the appliance to reach items could be seriously injured.
- Do not allow children to climb or play around the appliance. The weight of a child on an open oven door may cause the appliance to tip, resulting in serious burns or other injury. An open drawer when hot may cause burns.

# **⚠** WARNING

- Stepping, leaning, or sitting on the door or drawers of this appliance can result in serious injuries and also cause damage to the appliance.
- Never cover any slots, holes or passages in the oven bottom or cover and entire rack with materials such as aluminum foil. Aluminum foil linings may also trap heat, causing a fire hazard.
- Do not use oven or warmer drawer (if equipped) for storage.
- Never use your appliance as a space heater to heat or warm the room. Doing so may result in carbon monoxide poisoning and overheating of the appliance.



# CAUTION

- When heating fat or grease, watch it closely. Grease may catch fire if it becomes too hot.
- Do not use water or flour on grease fires. Smother fire or flame or use dry chemical or foam-type extinguisher. Cover the fire with a pan lid or use baking soda.
- Use dry potholders. Moist or damp potholders on hot surfaces may result in burns from steam. Do not let potholders touch hot cooking areas. Do not use towels or other bulky cloths.
- Do not heat unopened food containers - Build-up of pressure may cause container to burst and result in injury.

#### IMPORTANT SAFETY INSTRUCTIONS

# **A** CAUTION

- Wear proper apparel Loose-fitting or hanging garments should never be worn while using the appliance. Do not let clothing or other flammable materials contact hot surfaces.
- Do not touch surface burners or elements, areas near these burners or elements, interior surfaces of the oven, or the warmer drawer (if equipped). Surface burners and elements may be hot even though they appear cool. Areas near surface burners and elements may become hot enough to cause burns. During and after use, do not touch, or let clothing or other flammable materials touch these areas until they are cool. These areas may include the cooktop, surfaces facing the cooktop, oven vent areas, oven door, and oven window.
- Do not attempt to operate the appliance during a power failure. If the power fails, always turn off the appliance. If the appliance is not turned off and the power resumes, electric surface elements may resume operation when power is restored. Once the power resumes, reset the clock and the oven function.

# IMPORTANT INSTRUCTIONS FOR USING YOUR OVEN

Protective liners—Do not use aluminum foil, aftermarket oven liners, or any other materials or devices to line oven bottom, oven racks, or any other part of the appliance. Only use aluminum as recommended for baking, such as lining cookware or as a cover placed on food. Any other use of protective liners or aluminum foil may result in a risk of electric shock or fire or a short circuit.

Use care when opening oven door, lower oven door, or warmer drawer (some models). Stand to the side of the appliance when opening the door of a hot oven. Let hot air or steam escape before you remove or replace food in the oven.

Keep oven vent ducts unobstructed. Touching surfaces in this area when the oven is on may cause severe burns. Do not place plastic or heat-sensitive items on or near the oven vent. These items can melt or ignite.

Placement of oven racks - Always place oven racks in desired location while oven is cool. If rack must be moved while oven is hot, do not let potholder contact hot burner or element in oven. Use potholders and grasp the rack with both hands to reposition. Remove all cookware and utensils before moving the rack.

Do not use a broiler pan without its insert. Broiler pans and inserts allow dripping fat to drain away from the high heat of the broiler. Do not cover the broiler insert with aluminum foil; exposed fat and grease could ignite.

Do not cook food on the oven bottom. Always cook in proper cookware and always use the oven racks.

#### IMPORTANT INSTRUCTIONS FOR CLEAN-ING YOUR APPLIANCE

## **CAUTION**

Before manually cleaning any part of the appliance, be sure all controls are turned off and the appliance is cool. Cleaning a hot appliance can cause burns.

Clean the appliance regularly to keep all parts free of grease that could catch fire. Do not allow grease to accumulate. Greasy deposits in the fan could catch fire.

Always follow the manufacturer's recommended directions for use of kitchen cleaners and aerosols. Be aware that excess residue from cleaners and aerosols may ignite causing damage and injury.

Clean ventilating hoods frequently -Grease should not be allowed to accumulate on hood or filter. Follow the manufacturer's instructions for cleaning vent hoods.

#### IMPORTANT INSTRUCTIONS FOR SELF **CLEANING OVENS**



# **CAUTION**

Before using self clean, remove the broiler pan, any food, utensils, and cookware from the oven, storage drawer or warming drawer (if equipped). Remove oven racks unless otherwise instructed.

Do not clean the oven door gasket. The door gasket is essential for a good seal. Care should be taken not to rub, damage, or move the gasket.

Do not use a protective coating to line the oven and do not use commercial oven cleaner unless certified for use in a self-cleaning oven.

Use the self clean cycle to clean only the parts listed in this manual.

Some birds are extremely sensitive to the fumes given off during the self clean cycle of any oven. Move birds to another well-ventilated room.

## IMPORTANT SAFETY INSTRUCTIONS

#### IMPORTANT INSTRUCTIONS FOR **SERVICE AND MAINTENANCE**

Do not repair or replace any part of the appliance unless specifically recommended in the manuals. All other servicing should be done only by a qualified technician. This reduces the risk of personal injury and damage to the appliance.

Always contact your dealer, distributor, service agent, or manufacturer about problems or conditions you do not understand.

Ask your dealer to recommend a qualified technician and an authorized repair service. Know how to disconnect the power to the appliance at the circuit breaker or fuse box in case of an emergency.

Remove the oven door from any unused oven if it is to be stored or discarded.

Do not touch a hot oven light bulb with a damp cloth. Doing so could cause the bulb to break. Handle halogen lights (if equipped) with paper towels or soft gloves. Disconnect the appliance or shut off the power to the appliance before removing and replacing the bulb.



# WARNING

California Residents: for cancer and reproductive harm information, visit www.P65Warnings.ca.gov

**Special Features**Use the special features of your Frigidaire oven to get the best baking and roasting results.

Go	al	Feature		
	Steaks perfectly cooked to your preference Juicy pork and poultry	Air Sous Vide		
•	Eggs just as hard or soft as you like them Vegetables that remain firm and crisp	The precisely-controlled heat and airflow give you sous vide results without the water bath, preserving natural flavors and locking in moisture.		
•	Breads and pastries that rise higher with a	Steam Bake		
	crispy, golden crust and a light and flaky interi- or	Steam baking slows the formation of the crust, allowing your dough to grow longer before the crust forms.		
•	Moist and tender meats with a golden, crispy	Steam Roast		
	skin on the outside.	The humidity of steam roasting prevents meats from drying out during the cooking process.		
•	Golden, crispy chicken wings	Air Fry		
•	Crunchy vegetable chips Juicy chicken parmesan Perfectly crisp tempura shrimp, samosas, and more	The hot air convection makes crisp, golden fried foods without the splatter. For even heating on all sides and large capacity, use the Air Fry Tray (available from Frigidaire.com).		
•	Airy breads and balanced pizza dough	Bread Proof		
		Bread proofing keeps your oven at the best temperature and humidity for yeast to cause your dough to rise.		
•	Prepare convenience foods without delay	No Preheat		
		Get your culinary delights on the table faster		
•	Healthy, flavorful fruit snacks	Dehydrate		
•	Lean meat jerky Dried herbs	The dehydrate feature keeps the oven on low humidity and low heat to dry foods without cooking them.		
•	Perfectly browned baked goods	Advanced Convection		
•	Evenly cooked roasts and braises	Even your most challenging recipes turn out de- licious with the precisely-controlled heat and air circulation of Advanced Convection		
•	Roast turkey that's crispy on the outside and	Turkey Option		
	juicy on the inside.	Precisely times your convection roast for turkey that is perfectly done.		

Go	pal	Feature
ing task		Full-Color Touch Controls
		Operate your oven with ease with our intuitive Full-Color Touch Controls
Move food easily in and out of the oven		Luxury-Glide® Oven Racks
		Oven racks are so smooth they extend effortlessly
•	See clearly what's happening inside the oven	Luxury-Design® Lighting
		Get full visibility into the oven's interior with our ramp-up halogen Luxury-Design® Lighting
•	Prevent build-up of burrned, spilled food in the	One Hour Steam Clean
bottom of the oven		Keep your oven looking its best with the one hour Steam Clean cycle that's chemical- and odor-free

## **Bakeware**

The material of bakeware affects how evenly and quickly it transfers heat from the pan to the food.

Material	Attributes	Recommendation
Shiny metal bakeware	Shiny, aluminum, and non-coated bakeware is the best for even heating. It is suitable for all baked goods.	Recommended cooking temperatures and times are based on shiny metal bakeware.
Dark metal bakeware  Dark bakeware cooks hotter than shiny bakeware.		Reduce the cooking temperature by 25°F (13-14°C) when using dark bakeware.
Glass bakeware	Glass bakeware cooks hotter than shiny bakeware. Glass is convenient, as the same piece of bakeware can be used for cooking, serving, and storing food.	Reduce the cooking temperature by 25°F (13-14°C) when using glass bakeware.
Insulated bakeware	Insulated bakeware cooks cooler than shiny bakeware. Insulated bakeware is designed for baking in gas ovens.	When using insulated bakeware, the recipe baking time may be longer than usual.

#### **Cooking Conditions**

Conditions in your kitchen can affect the performance of your appliance when cooking food.

Condition	Attributes	Recommendation	
Aging cookware	As pans age and become discolored, cooking times may need to be reduced slightly.	If food is too dark or overcooked, use the minimum cook time in the recipe or packaging.	
		If food is too light or undercooked, use the middle to maximum cook time in the recipe or packaging.	
High altitude	Air is drier and air pressure is lower.	Adjust cooking temperature, cooking time, or recipes as needed.	
	Water boils at a lower tem-	Increase amount of liquid in baking recipes.	
	perature, and liquids evaporate faster.	Increase cook time on cooktop. Cover dishes to reduce evaporation.	
	Foods may take longer to bake.	Increase bake time or oven temperature.	
Doughs may rise faster.		Reduce amount of baking soda or baking powder in recipe. Reduce rising time or punch down dough and allow it to rise twice.	

## **Cooking Results**

Small adjustments may help you achieve the best results.

Result	Recommendation		
Food too light	Use the middle to maximum cook time recommended on packaging or recipe.		
Food too dark	Use the minimum cook time recommended on packaging or recipe.		

# **Cooking Tips**

Use these additional tips to get the best results from your appliance.

Situation	Recommendation	
Baking		
Rack placement	Follow the instructions in particular oven mode starting in "Setting Oven Cortrols" on page 20.	
Preheat	Fully preheat the oven before baking items like cookies, cakes, biscuits and breads. Insert food immediately after the beep.	
Checking food	Use the window and oven light when checking food. Opening the door may reduce baking performance.	
Bake or Convection Bake	ake Convection bake is the best function to use for baking on multiple racks. F best performance, see."Convection Bake" on page 24	
Steam Bake	For directions, tips, and benefits of Steam Bake see "Steam Bake" on page 36.	
Food placement	Allow at least 2 inches (5 cm) of space between bakeware for proper air circulation.	

Material	Recommendation				
Broiling / Roasting	Broiling / Roasting				
Broiling pan	For best results when broiling, use a broil pan with an insert designed to drain the fat from the food, help avoid spatter, and reduce smoking. The broiler pan will catch grease spills, and the insert helps prevent grease splatters.				
<b>Convection Cooking</b>					
Convection attri- butes	Convection cooking uses a fan to circulate hot air around the oven and food. It browns food more evenly and reduces hot spots in the oven.				
	Convection saves time when using multiple racks or cooking several food items at once.				
Convection bake	Reduce cooking temperature by 25° F (13-14° C) from the recipe unless the recipe is written for convection baking.				
	Preheat the oven for best results.				
Convection roast	Convection roast is best for meats and does not require preheating for most meats and poultry.				
	Reducing the cooking temperature for convection roast is not recommended. Carefully follow your recipe's temperature and time recommendations, adjusting the cooking time if the recipe does not specify convection roasting time.				
	Since convection roast cooks faster, cook time may be reduced by 25% to 40% depending on food type. You can reduce cook times by 25% from the recommended time of your recipe, and check the food at this time. If needed, continue cooking until the desired doneness is obtained.				
	Use the meat probe included with your appliance. Meat probes are also available from most grocery and home goods stores.				
	Arrange oven racks so large cuts of meat and poultry are on the lowest rack of the oven.				
	Do not cover foods when dry roasting - covering will prevent the meat from browning properly.				
	When cooking meats, use the broiler pan and insert or a roasting rack. The broiler pan will catch grease spills and the insert helps prevent grease splatters.				



#### **IMPORTANT**

Your Frigidaire wall oven has many features that allow you to customize the way your oven works.

Take time to read this section for important safety information and to become familiar with the many menu option settings starting on page 16.

#### **Oven Vent Location**

The oven is vented as shown below. When the oven is on, warm air is released through the vent. This venting is necessary for proper air circulation in the oven and good baking results. Do not block oven vent. Never close off the openings with aluminum foil or any other material. Steam or moisture may appear near the oven vent. This is normal.




Figure 1: Oven vent



#### **WARNING**

Protective Liners — Do not use aluminum foil or any other material or liners to line the oven bottom, walls, racks or any other part of the range. Doing so will alter the heat distribution, produce poor baking results, and possibly cause permanent damage to the oven interior. Improper installation of these liners may result in risk of electric shock or fire. During self clean, temperatures in the oven will be hot enough to melt foil.



## **CAUTION**

Always use pot holders or oven mitts when using the oven. When cooking, the oven interior, oven exterior, oven racks, and cooktop will become very hot which can cause burns.

Remove all oven racks before starting a self clean cycle. If oven racks are left inside the oven during a cleaning cycle, the slide ability of the oven racks may be damaged and all of the oven racks will lose their shiny finish.

To prevent possible damage to the oven, do not attempt to close the oven door until all the oven racks are fully positioned back inside the oven cavity.

#### **Types of Oven Rack**




Figure 2: Oven rack types

- Flat oven racks may be used for most cooking needs and may be placed in most oven rack positions.
- The fully extendable glide rack makes food preparation easier. This oven rack has glide tracks that allow the rack to be pulled away from the oven without rubbing the sides of the oven wall. See glide rack instructions on next page.




## **WARNING**

Do not line the oven walls, racks, bottom or any other parts of the range with aluminum foil. Doing so will alter heat distribution, produce poor baking results and may cause permanent damage to the oven interior. During self-clean temperatures the oven will be hot enough to melt foil.


Removing and Replacing the Glide Racks

The fully extendable Glide rack makes food preparation easier. This oven rack has glide tracks that allow the rack to be pulled away from the oven without rubbing the sides of the oven wall.


**To remove** - Make sure the baking rack is in the closed position. Using one hand, reach through handle opening and grasp both the upper and lower bars of the glide rack.



While holding both sections, pull the glide rack out of the oven until the stop position is reached.



Using both hands, lift up the front of the rack slightly and continue to pull the rack away from the oven. Be sure to grasp both upper and lower rack portions together when removing or handling the glide rack.



The rack portions move independently and are difficult to handle unless held together.

**To replace** - Make sure the baking rack is in the closed position. Grasp both upper and lower portions of glide rack. Lift and hold the rack level between the oven cavity walls. Tilt the front of the rack upward slightly and slide the rack completely into position.

To prevent possible damage to the oven, do not attempt to close the oven door until all the oven racks are fully positioned back inside the oven cavity.



## **IMPORTANT**

Remove all oven racks and clean according to instructions provided in the Care & Cleaning section of this manual. Never pick up hot oven racks or parts.

# Using Menu Options to Customize Your Cooking Experience

When you first install your appliance, the screen will prompt you to set your preferences. You can always change them later using the menu  $\equiv$  .


- 1. Touch the Menu Options bars and scroll to find the desired option.
- 2. Select option and set your preference.
- 3. Save and go back or Save & Close.

You can press the  ${\bf X}$  to close without saving changes.

#### Clock

When the appliance is first plugged in or when the power supply to the appliance has been interrupted, the display will show 12:00. It is recommended to always set the clock for the correct time of day before using the appliance.


- 1. Touch **Menu Options** bars and scroll to **Clock**. You will see options to turn off the clock display when the oven is off, to change from 12-hour to 24-hour time, and to set the clock.
- 2. Touch **Set Clock** and set time using graph.
- 3. Set AM or PM
- 4. Save & Close



#### **Energy Saving Mode**


The oven control has a factory preset built-in 12-Hour Energy Saving feature that will turn off the oven if the oven is left on for more than 12 hours. The control may be programmed to override this feature to bake continuously.

- 1. Scroll to **Energy Saving Mode** and touch.
- 2. Follow the information to override the Energy Saving feature if necessary.
- 3. Save & Close.



#### **General Settings**

- 1. Scroll to **General Settings** and touch.
- 2. Different options will appear.
- 3. Select an option to see how it is set and change if desired.



#### **Temperature Display**

The electronic oven control is set to display  $^{\circ}F$  when shipped from the factory. The display may be changed to show either  $^{\circ}F$  or  $^{\circ}C$  oven temperatures.

Temperature Display > O Fahrenheit O Celcius

- 1. Select Fahrenheit or Celcius.
- 2. Save & Close

#### Volume

Volume allows the oven control to operate with strong tones, quiet tones, or no tones. Use the slider to set the volume.



#### **Screen Brightness**



1. Choose brightness and Save & Close.

#### Language



- 1. Select desired language.
- 2. Save & Close.

#### **Favorites**

Scroll to Favorites and touch.

- Quick Start Options > Oven 350°F (can change the default when Quick Start is selected)
  - 1. Change temperature if desired.
  - 2. Save.
- Temperature Options > Adjust Custom Preheat default.
  - 1. 325°F / 163°C
  - 2. 375°F / 191°C
  - 3. 400°F / 204°C



### **NOTE**

These temperature options are also available in Custom Preheat menu on the main screen

#### **Cooking Tips**

You can switch whether cooking tips are displayed or not by choosing On or Off.


#### **Oven Temperature Calibration**

Your appliance has been factory calibrated and tested to ensure an accurate baking temperature. For the first few uses, follow your recipe times and temperature recommendations carefully. If you think the oven is cooking too hot or too cool for your recipe times, you can adjust the control so the oven cooks hotter or cooler than the temperature displayed.

**Important:** Do not use oven thermometers such as those found in grocery stores to check the temperature settings inside your oven. These oven thermometers may vary as much as 20 to 40 degrees from actual temperatures.


- 1. Scroll to **Oven Temperature Calibration** and touch.
- 2. Option to adjust is shown.
- 3. Use slide to increase or decrease default oven temperature.
- 4. Save and go back or Save & Close.

The oven temperature may be increased as much as  $+35^{\circ}F$  (+19°C) or decreased -35°F (-19°C) from the factory calibrated settings.



#### Sabbath Mode

- 1. Scroll to Sabbath Mode.
- Read and follow all instructions to set and when finished cancel. See "Setting the Sabbath Feature for the Jewish Sabbath and Holidays (some models)" on page 46 for complete details on how Sabbath mode works with your oven controls.



#### **Factory Reset**

- 1. Scroll to Factory Reset and touch
- 2. Follow screen prompts

Note: Your appliance was set with predetermined (default) oven control settings. Over time, users may have made changes to these settings. The following options may have been modified since the appliance was new:

- 12 or 24 hr display mode
- Screen Brightness
- Language
- Favorites
- Show Clock
- All Food Probe settings
- Continuous bake or 12 hour energy savings mode
- Silent or audible control
- Oven temperature display (Fahrenheit or Celsius)
- Oven temperature adjustments (UPO)

If Reset is touched all the settings will return to default.

- 3. Are you sure?
- 4. Reset.
- 5. OKAY






#### **Food Probe**


Food probe options can be found in the Settings menu and the Oven Modes menu. Select Food Probe from the Settings menu to select whether the oven turns off or stays on when the specified temperature is reached during cooking.

- 1. Scroll to Food Probe and touch.
- 2. Follow instructions on the display.



#### **Lock Screen**

As a safety measure the oven doors and controls can be locked. Follow screen directions to lock and unlock.



From the Settings Menu, Select **Lock Screen**, then touch and hold **LOCK** for 3 seconds.

When the doors and controls are locked the screen will show the time of day, a note that the oven is locked, and an **UNLOCK** key. Once the controls and door are locked, there is no access to any cooking functions. This ensures that the oven will remain locked and safe.

To unlock the oven door, press the **UNLOCK** key, Once the controls and door are locked, there is no access to any cooking functions.

To unlock the oven door and control, press **UN-LOCK** and follow directions on the screen. You will be shown a code to use for unlocking the doors and controls.

Enter code shown below to unlock screen				
382 CODE TO E		CODE	X CLEAR	UNLOCK
1	2	3	4	5
6	7	8	9	0

#### **About the Appliance**


- 1. Scroll to **About the Appliance** and touch.
- 2. Touch headings to see information.

Important information about the appliance such as the the software version number and contact information for support is listed here.



#### ON / OFF

When **ON/OFF** is pressed, the display opens to the Quick Start screen.



# NOTE

In addition to ON/OFF, touching the screen will also activate the display.

If the oven is on when **ON/OFF** is pressed, it will turn off completely, canceling any functions that are running at the time.

#### **BACK**

Pressing the Back key will return to the previous screen without implementing any changes you may have selected.

#### TIMER

Pressing Timer will access the timer function. The timer will count down the amount of time you specify, and a tone will sound when the timer reaches zero. You can set a timer from 1 minute to 11 hours and 59 minutes.

Enter the desired time and press **START**. While the timer is running, you can pause or cancel the countdown. You can also add or subtract time by pressing + or -.

#### **LIGHT**

Press the Light key to turn the oven light on or off.


Table 1: Minimum and maximum control settings

Table 1: Minimum and maximum control settings				
Feature	Mode	Min Temp/ Time	Max Temp/ Time	
No Preheat		170°F (77°C)	550°F (288°C)	
Bake		170°F (77°C)	550°F (288°C)	
Broil		400°F (205°C)	550°F (288°C)	
Air Fry		170°F (77°C)	550°F (288°C)	
Sous Vide		100°F (38°C)	205°F (94°C)	
Steam Bake		170°F (77°C)	550°F (288°C)	
Steam Roast		170°F (77°C)	550°F (288°C)	
Conv Bake		170°F (77°C)	550°F (288°C)	
Conv Roast		170°F (77°C)	550°F (288°C)	
Food Probe		140°F (60°C)	210°F (99°C)	
Keep Warm		140°F (60°C)	200°F (93°C)	
Bread Proof		100°F (38°C)	11:59 Hr./Min	
Dehydrate		95°F (35°C)	170°F (77°C)	
Timer		0:01 Min	11:59 Hr./Min.	
Clock Time	12 Hr.	1:00 Hr./Min.	11:59 Hr./Min.	
	24 Hr	0:00 Min	23:59 Hr./Min.	
Delay Start		0:01 Min.	1:00 Hr./Min.	
Cook Time	12 Hr.	0:01 Min	11:59 Hr./Min.	
	24 Hr	0:01 Min	11:59 Hr./Min.	
Self clean		2 hours	4 hours	


#### **Quick Start**

When **ON/OFF** is pressed the display opens to the Quick Start screen.

From the Quick Start screen, you can immediately start the Bake function by pressing **START**. You can adjust the temperature by pressing **+** or **-**.



To select other cooking options, touch **Oven Modes** and scroll to the desired feature:



Use the scroll bar to find your oven mode as shown in the oven mode table on the right. When you select a cooking mode simply follow the tips for setting the particular mode.

**Important:** Valuable tips to help you get the best results are included in the display and also can be found in this Use & Care Manual.

#### Modes

- Bake (page 22)
- Convection Bake (page 24)
- Air Fry (page 25)
- No Preheat (page 26)
- Slow Cook
  - Air Sous Vide (page 27)
  - Dehydrate (page 30)
  - Bread Proof (page 30)
  - Slow Cook (page 31)
- Convection Roast (page 31)
- Broil (page 33)
- Multi-Rack (page 35)
- Steam Bake (page 36)
- Steam Roast (page 37)
- Keep Warm (page 37)
- Delay Start (page 38)
- Self Clean (page 39)
- Steam Clean (page 42)
- Food Probe (page 43)

#### **Setting Bake**

Bake uses heat that rises from the oven bottom for best baking results.

A reminder tone will sound indicating when the set bake temperature is reached and to place the food in the oven.

Bake may be set for any oven temperature between 170°F (77°C) to 550°F (288°C).




#### **CAUTION**

Always use pot holders or oven mitts when using the oven. When cooking the oven interior, oven racks, and cooktop will become very hot which can cause burns.


#### **Baking Tips**

- Fully preheat the oven before baking items like cookies, cakes, biscuits and breads.
- For all baking except layer cakes, pans should be pulled to the front of the rack. Place layer cake pans as shown.
- Use the convection bake function for best results when baking cookies or cakes on multiple racks.
- For best results when baking layer cakes using two oven racks, place racks in positions 2 (flat) and 5 (glide) and place pans centered on each rack.
- When using any single rack for baking cookies, cakes, biscuits, or muffins use rack position 3.
- Allow at least 2 inches (5 cm) of space between bakeware for proper air circulation.
- Leave oven lights off while baking.



#### To set Bake

1. Press **ON/OFF** key.



- Touch Oven Modes and touch Bake. The default temperature 350°F will show in the display. You can also use the controls on the Quick Start screen.
- 3. To set the temperature to 375, use the numbered keys to program the new temperature of 375 and touch **START**.
- 4. The screen shows the current temperature and a Cook Time button.
- 5. Touch Cook Time to set a cooking time if need-

**NOTE**: If a cook time is set the oven will turn off automatically when the time expires.

- Touch START.
- 7. When cooking has ended, **Off** will be in display.
- 8. Press **ON/OFF** to return display to show the time of day.

To cancel cooking anytime touch CANCEL.

Press **ON/OFF** to turn off the oven and show time of day in the display.

To cancel cooking anytime touch CANCEL.



#### **Setting Cook Time**

Use Cook Time to set the amount of time needed for most oven functions. The oven will turn on immediately (or after a specified delay) and stop automatically after the set cook time ends.

In most cases you will see a cooking tip suggesting to set Cook Time after the oven is preheated.

#### When the programmed cook time ends:

- Off will appear in the display window
- an alert tone will sound
- the oven will turn off automatically The **Off** message and an **OKAY** button will display until **OKAY** is touched.



**NOTE:** The maximum cook time setting is 11 hours and 59 minutes unless the oven is set for continuous cooking.

#### To change the oven temperature or cook time after baking has started:

- Touch + or on either side of the set temperature.
- Touch **TEMP** to access the keypad.

#### **Convection Bake**

Convection Bake uses a fan to circulate the oven's heat uniformly around the oven. This improved heat distribution allows for even cooking and browning results. Heated air flows around the food from all sides.

Convection bake may be set for any oven temperature between 170°F (77°C) and 550°F (288°C).

#### Benefits of convection cooking include:

Multiple rack baking.

#### Convection baking tips:

- Use Convection Bake for best results when baking cookies and cakes on 2 racks.
- For best results it is recommended to preheat the oven before baking items like cookies, biscuits and breads and move pans to front of the racks.
- If your recipe is not written for convection baking, reduce the oven temperature by 25° or use Convection Convert option.
- No special pans or bakeware required.
- For cookies use the following racks:
- Single rack baking use 3 (flat rack).
- Two rack baking use 2 (flat) and 5 (glide).
- For baking cakes use the following rack positions and place bakeware as shown in Figure 4.
   In upper rack use position 4 (glide) or 5 (flat).
- Cookies and biscuits should be baked on pans with no sides or very low side to allow heated air to circulate around the food. Food items baked on pans with a dark finish will cook faster.
- Leave oven lights off while baking.

#### **Convection Convert**

Convection Convert automatically reduces the oven temperature from what is specified in most baking recipes to compensate for the increased cooking efficiency of convection baking.

# To set convection bake with a default oven set temperature of 325°F (163°C):

- Select Oven Mode and scroll to Convection Bake.
- 2. Touch **Convection Bake**: Default oven temp of 325° appears.
- An option for Convection Convert is visible on the screen. Using it will lower the oven temperature 25° to account for the increased efficiency of convection. If used, Convection Convert must be selected before pressing Start.
- 4. Touch **START**:
- 5. Option to set **Cook Time**.
- 6. Touch START.
- 7. Oven will turn off when **Cook Time** is complete.
- 8. Cooking has ended and Off will be in display.
- 9. Press **ON/OFF** to return display to show the time of day.

OVEN				Ξ
Convection Convert		325°	X [	START
1	2	3	4	5
6	7	8	9	0




Figure 3: Pan positions for best results when baking cakes on two racks.

#### Air Frv

The Air Fry feature works best for single rack baking with packaged and convenience foods. It works well with most recipes and can be programmed for temperatures between 170°F and 550°F. Follow the recipe or package directions for food preparation quantity, time, and temperature.

#### Important:

- Food should be arranged in single layers on the air fry tray and placed on rack position 3 for best results.
- When using the Air Fry tray, place a large cookie sheet on rack position 1 to catch any crumbs or drippings.
- Leave oven light off when baking.
- Food may need to be removed early and should be checked at minimum recommended bake time. However, frozen dense foods and items with cook times less than 15 minutes may require additional time.

#### To set the Air Fry function:

- 1. Arrange food on rack as suggested.
- 2. Select Air Frv from Oven Modes.
- 3. Enter the suggested temperature for particular food. Touch **START**.
- 4. Press **START**. When preheat tone sounds place the tray on rack position 3 and to prevent smoke, place a baking sheet on rack position 1 below the Air Fry Tray.
- 5. If setting a Cook Time, set after the oven is preheated. Cook time turns off Air Fry when
  - finished. NOTE: Setting the timer for the minimum suggested time after preheat is a good option and checking food for doneness.

- 6. When cook time ends **Off** will be in display.
- 7. Press **ON/OFF** to return display to show the time of day.

The Air Fry Tray is specifically designed to deliver superior performance.

#### Some Benefits of the Air Fry Tray:

- Tray optimized for oven space and large capacity air frying.
- Fits in the dishwasher for easy clean up.
- Higher yield than countertop models.
- Frees up countertop space.




Figure 4: Air Fry Tray



#### NOTE

If you don't have an air fry tray, you can purchase one from frigidaire.com.

**Table 2: Air Fry Table** 

Food Type	Quantity (oz.)	Temperature	Cook Time (mins)	
Frozen Tater Tots	48	450°F - 232°C	29-33	
Frozen Golden Fries	48	425°F - 218°C	25-35	
Frozen Chicken Nuggets	48	400°F - 205°C	13-15	
Frozen Crispy Chicken Strips	48	400°F - 205°C	20-22	
Frozen Hot Wings Bone-In	48	450°F - 232°C	25-28	
Frozen Chicken Wings	48	375°F - 190°C	60-65	
Fresh Chicken Wings	48	450°F - 232°C	30-40	

#### **No Preheat**

No Preheat is available for single rack baking with packaged and convenience foods and can be used with regular recipes also. No Preheat may be used with temperatures between 170°F and 550°F. Follow the recipe or package directions for food preparation time and temperature.

During No Preheat function, the oven elements will cycle on and off. The convection fan will turn on and stay on until No Preheat is canceled. Depending on your preference for doneness cooking times may vary. Watch food closely.



#### **CAUTION**


Always use pot holders or oven mitts when using the oven. When cooking the oven interior, oven racks, and cooktop will become very hot which can cause burns.

#### Important:

- Always place food on rack position 3.
- Place the food with the pan or bakeware to the front of the oven rack.
- When using No Preheat, use bakeware with low or no sides. This allows the air to circulate around the food evenly.
- · Leave oven light off when baking.
- Food that comes in strips, such as fish sticks and chicken tenders, should be placed on the pan with the ends pointing to the sides of the oven. Follow the package directions for food preparation time and temperature.
- Food may need to be removed early and should be checked at minimum recommended cook time.
- No Preheat works best when cooking foods longer than 10 minutes. If directions call for a shorter cooking time, a few extra minutes may be required for optimal cooking results.
- Do not open the oven door often. Opening the door will reduce the temperature in the oven and may increase cook time.
- · Leave oven lights off while cooking.

#### To set the no preheat temperature for 350°F:

- 1. Arrange the interior oven racks.
- 2. Press ON/OFF key.
- 3. Touch Oven Modes and scroll to No Preheat.
- 4. Follow No Preheat tips and set temperature or use 350°F (default).
- 5. Touch **START**.





- Set Cook Time if needed.
- 7. Touch **START**.

**NOTE**: If a cook time is set the oven will turn off automatically when the time expires. Foods with a cook time under 10 minutes may need extra time.

- 8. When cooking has ended, Off will be in display.
- Press ON/OFF to return display to show the time of day.

To cancel cooking anytime touch **CANCEL**.





#### Air Sous Vide

Air Sous Vide is ideal for cooking meats to achieve tenderness without overcooking.

How Sous Vide Works

Sous vide is a French phrase meaning "under vacuum". In sous vide cooking, food is vacuum-sealed in plastic pouches, which are then placed in a cooking medium of hot water or air.

Your appliance uses hot air circulating around sealed pouches to cook food slowly at relatively low temperatures: 100°F to 205°F (38°C to 94°C). Sous vide cooking is not fast, but with a little planning, it can be very easy.

#### **Advantages of Sous Vide**

- Food does not lose flavor or aroma due to evaporation.
- Vitamins and minerals do not escape during cooking.
- The low cooking temperature leaves meat and fish more tender.
- Less spice is needed, as food keeps more of its natural flavor.
- The low cooking temperature greatly reduces the risk of overcooking. The food never gets hotter than the intended serving temperature.
- Timing is less critical. If different dishes are finishing at different times, food that has reached serving temperature can wait, since it stays at serving temperature in the cooking medium.

#### Food Safety

Because sous vide cooks at relatively low temperatures, safe food handling is especially important.:

- Always keep raw food in safe conditions before vou start cooking.
- Clean the raw food before you start cooking.
- Use Table 1, "Recommended Sous Vide Cook Settings," to find the recommended cooking time and temperature for the food.
- Only use temperatures below 140°F (60°C) to cook foods that can be safely eaten raw.
- Food should be between 34°F and 37°F (normal refrigerator temperatures) when preparing to place food in sous vide vacuum pouch.
- Sous vide dishes are best served immediately after cooking. If food is not served immediately, use an ice bath to chill it quickly and then keep it refrigerated for up to 3 days.
- Do not use sous vide to reheat leftovers.
- Do not allow raw food to contact cooked food during preparation. Do not use the same tools on different food items without washing them.
- If the recipe includes raw eggs, keep the whites and yolks from touching the outsides of the shells.
- Blanching in boiling water or searing in a pan before sous vide cooking can destroy surface bacteria to improve food safety.
- Do not use Delay Start with the Sous Vide function.
- Do not use a meat probe with the Sous Vide function. Food needs to be sealed air-tight in a pouch for sous vide cooking.

#### Vacuum Sealing

Sous vide cooking in your oven requires a vacuum sealer and vacuum pouches. The pouch needs to be sealed so no air or liquid can leak out. A pouch that leaks will produce poor cooking results and may produce smoke and residue that can burn during future cooking or when using self-clean. Follow the instructions that come with your sealer and pouches.

- Use pouches that are specified for your sealer and for sous vide cooking.
- Do not reuse vacuum pouches.
- Put food in one layer in the pouch for even cooking.
- It is recommended to use one food portion per vacuum pouch.
- For most sous vide cooking, use the highest vacuum setting for best cooking results.
- Make sure that the closure of the pouch is clean to get a good seal. If cooking at higher temperatures (above 160° F / 71° C), double-seal the pouch.
- Vacuum pouches are solely for sous vide cooking and should not be used for regular baking or broiling.

## **Sous Vide Cooking**

- 1. Prepare
- Start with the freshest, highest quality food possible.
- Clean and cut the ingredients.
- 2. Package
- Place the ingredients in the plastic pouch for your vacuum sealer. Add seasonings for cooking.
- Note: If cooking multiple items at once, you
  may want to write the contents on the outside
  of the pouches before filling and sealing them.
- Vacuum seal the pouch, removing as much air as possible. Verify that you have achieved an air-tight seal.
- If not cooking immediately, store the pouch in a refrigerator until ready to cook.

#### To cook Air Sous Vide:

- Touch Oven Modes and scroll to Slow Cook, then choose Air Sous Vide from the sub-menu.
- 2. Touch **Air Sous Vide**: display shows 130°F (54°C) setting as default.

OVEN				=
	1	30°	X CLEAR	START
1	2	3	4	5
6	7	8	9	0

- 3. Set desired temperature.
- 4. Touch START.

**IMPORTANT:** Since sous vide cooking allows for a suggested minimum cooking time and a target time, it is recommended to set the timer to at least the minimum time or to any time up to the target suggested time. With sous vide cooking, there is a maximum cooking time which allows the user more flexibility when cooking with no specific end time.

**Note:** Use the settings recommended for the type of food in Table 3 on page 29.

- 5. Finish
- Open the plastic pouch and remove the food.
- You may finish the food with a final searing or grilling to achieve a nice crust and roast flavor.
- Add final seasonings or sauces if needed.
- Serve.



#### CAUTION

Even though sous vide cooks at relatively low temperatures, use care when handling the pouch and its contents, which will be hot to the touch.

Only use temperatures below 140°F (60°C) for cooking foods that can be safely eaten raw.

#### **IMPORTANT**

The U.S. Department of Agriculture states, "Rare fresh beef is popular, but you should know that cooking it to only 140°F (60°C) means some food poisoning organisms may survive." (Source: Safe Food Book, Your Kitchen Guide, USDA) The lowest temperature recommended by the USDA is 145°F (63°C) for medium rare fresh beef. For beef medium 160°F, well done 170°F (77°C). Visit the USDA Food Safety and Inspection website at www.fsis. usda.gov.

**Table 3: Sous Vide Table** 

Food	Doneness	Temperature		Cooking Time			
			Minimum	Target	Maximum		
Beef	•	•					
Steak	Rare	130° F / 54°-55° C	2 hours	3 hours	4 hours		
Steak	Medium Rare	135º F / 57º-58º C	2 hours	3 hours	4 hours		
Steak	Medium	145º F / 62º-63º C	2 hours	3 hours	4 hours		
Steak	Medium Well	150° F / 65°-66° C	2 hours	3 hours	4 hours		
Steak	Well	160° F / 71°-72° C	2 hours	3 hours	4 hours		
Roast	Rare	135º F / 57º-58º C	6 hours	7 hours	16 hours		
Roast	Medium Rare	140° F / 60° C	6 hours	7 hours	16 hours		
Roast	Medium	150° F / 65°-66° C	6 hours	7 hours	16 hours		
Roast	Medium Well	155º F / 68º-69º C	6 hours	7 hours	16 hours		
Roast	Well	160° F / 71°-72° C	6 hours	7 hours	16 hours		
Chuck/Brisket	Rare	140° F / 60° C	20 hours	24 hours	48 hours		
Chuck/Brisket	Medium Rare	150° F / 65°-66° C	20 hours	24 hours	48 hours		
Chuck/Brisket	Well	180° F / 82°-83° C	20 hours	24 hours	48 hours		
Pork	•	<u>'</u>			•		
Chop	Medium	150° F / 65°-66° C	2 hours	3 hours	4 hours		
Chop	Well	160° F / 71°-72° C	2 hours	3 hours	4 hours		
Roast	Medium	150° F / 65°-66° C	2 hours	3 hours	4 hours		
Roast	Well	180° F / 82°-83° C	2 hours	3 hours	4 hours		
Shoulder/Belly	Medium	150° F / 65°-66° C	10 hours	24 hours	48 hours		
Shoulder/Belly	Well	180° F / 82°-83° C	10 hours	24 hours	48 hours		
Chicken							
Parts	Tender	170° F / 76°-77° C	2 hours	2-1/2 hours	4 hours		
Fish							
Steak	Tender	105° F / 40°-41° C	1 hour	1-1 <sub>1/2</sub> hours	2 hours		
Steak	Flaky	125° F / 51°-52° C	1 hour	1-1 <sub>1/2</sub> hours	2 hours		
Steak	Well	145° F / 62°-63° C	1 hour	2 hours	2 hours		
Fillet	Tender	105° F / 40°-41° C	45 mins	1 hour	1 1/2 hours		
Fillet	Flaky	125º F / 51º-52º C	45 mins	1 hour	1 1/2 hours		
Fillet	Well	145º F / 62º-63º C	45 mins	1 hour	1 1/2 hours		
Vegetables		·					
Squash	Cubes	180° F / 82°-83° C	1 hour	1 1/2 hours	4 hours		
Roots	Sliced/Cubes	180° F / 82°-83° C	1 hour	1 1/2 hours	4 hours		
Potatoes	Sliced/Cubes	200° F / 93°-94° C	1 hour	1 1/2 hours	4 hours		
Fruits	· · · · · · · · · · · · · · · · · · ·	· · · · ·					
Warm/Ripe	Sliced/Cubes	155° F / 68°-69° C	45mins	105 mins	2 1/2 hours		
Soft	Purees	180° F / 82°-83° C	15 mins	30 mins	90 minutes		
		hicker cuts may require l					

# **30**

# **SETTING OVEN CONTROLS**

#### **Dehydrate**

For best results when dehydrating food use the Air Fry tray which allows air to circulate all around the food for faster preservation.

#### **Tips**

- Always use clean equipment and utensils.
- Keep meat and poultry refrigerated -- 40°F (4°C) or slightly below -- before dehydrating.
- Cut food in evenly sized pieces. Slices should be even and ¼ to ½ inch thick. This will ensure all pieces are dehydrated at same time.
- Use good quality fruits, vegetables, and meats.
   Overripe or bruised fruits and vegetables may turn black while dehydrating.
- Use lean cuts of meat or trim off excess fat.
- Use a paper towel to dry meat before dehydrating.
- Store dehydrated foods in airtight containers. If moisture appears in containers, the food was not dehydrated properly.
- Follow USDA recommendation when dehydrating.

#### To set Dehydrate:

- 1. Arrange food in a single layer on the Air Fry tray.
- 2. Touch **Oven Modes** and scroll to **Slow Cook**, then choose **Dehydrate** from the sub-menu.
- Set dehydrate temperature (between 95°F -170°F).
- 4. Touch **START**.
- 5. Press **ON/OFF** to end cooking and return display to show the time of day.



#### NOTE

Check food for doneness. If any moisture is present, allow food to dehydrate longer.


# Table 4: Dehydration Temp and Time Suggestions


Food	Temperature	Hours	Food	Temperature	Hours
Herbs, flowers	95°F - 35°C	6-10	Citrus Peel 8 - 15 hours	135°F - 57°C	8-15
Vegetables Tomatoes Peppers Mushrooms	125°F - 52°C	8-20 6-12 6-12	Fruit Apples Bananas Strawberries Peaches	145°F - 63°C	5-7 8-20 8-20 12-18
Meat	165°F - 74°C	6-18	Fish	145°F - 63°C	8-12
Root Vegetables	165°F - 74°C	C 10	Fruit Rolls/Leather	165°F - 74°C	8-18
Carrots Potatoes		6-10 10-15	Nuts and Seeds	150°F - 66°C	8-20

#### **Bread Proof**

Bread proofing creates the best conditions for yeast to multiply and cause your dough to rise.

- Touch Oven Modes and scroll to Slow Cook, then choose Bread Proof from the sub-menu.
- 2. Touch **Bread Proof**: Shows **Bread Proof 100°F** (38°C).
- 3. Touch START.





Check often to prevent over-proofing.

#### Slow Cook

Use Slow Cook for foods that will cook or braise at low temperature for a long period of time.

#### For best results when using Slow Cook:

- Completely thaw all frozen foods before cooking.
- When using a single oven rack, place in oven rack position 2 or 3. Position racks to accommodate the size of various bakeware when cooking multiple food items.
- Do not open the oven door often or leave the door open when checking foods. If the oven heat escapes often, the Slow Cook time may need to be extended.
- Cover to keep foods moist or use a loose or vented type cover to allow foods to turn crisp or brown.
- Roasts may be left uncovered so browning can occur. Cook times will vary depending on the weight, fat content, bone, and the shape of the roast. Preheating the oven will not be necessary when using the Slow Cook feature.
- Add any cream or cheese sauces during the last hour.

Slow cooking meats may result in the outside of the meat turning dark; this is normal.

#### To set Slow Cook:

- Touch Oven Modes and scroll to Slow Cook, then choose Slow Cook from the sub-menu.
- The display shows 175°F (79°C) setting as default. Use the numbered keys to program a different temperature if desired. Touch **START**.
- 3. The screen shows the current temperature and a **Cook Time** button.
- 4. Touch **Cook Time** to set a cooking time if needed.
  - **NOTE**: If a cook time is set, the oven will turn off automatically when the time expires.
- 5. Touch START.
- 6. When cooking has ended, **Off** will be in display. Press **OK** to return to the start screen.

Press **ON/OFF** to turn off the oven and show time of day in the display.

To cancel cooking at any time, touch CANCEL.

#### **Convection Roast**

Convection roast combines a cook cycle with the convection fan and elements to rapidly roast meats and poultry. Heated air circulates around the meat from all sides, sealing in juices and flavors. Meats cooked with this feature are crispy and brown on the outside while staying moist inside.



#### **WARNING**

Should an oven fire occur, close the oven door and turn the oven off. If the fire continues, use a fire extinguisher. Do not put water or flour on the fire. Flour may be explosive and water can cause a grease fire to spread and cause personal injury.



#### **CAUTION**

Always use pot holders or oven mitts when using the oven. When cooking, the oven interior, oven racks, and cooktop will become very hot which can cause burns.

# To use convection roast at a temperature of 350°F (177°C):

- Touch Oven Mode and scroll to Convection Roast.
- 2. Touch Convection Roast.
- 3. Set desired temperature or use default of 350°.
- 4. Touch START.
- Option to set Cook Time.
- 6. Touch **START**. Preheating the oven is not necessary.
- 7. When cooking is completed or to cancel Convection Roast press **ON/OFF**.




Figure 6: Convection roasting on lower oven racks

#### **Convection Roasting tips:**

- Preheating for convection roast is not necessary for most meats and poultry.
- Arrange oven racks so meat and poultry are on the lowest rack of the oven.
- Since convection roast cooks faster, may be able to reduce cook times as much as 25% from the recommended time of your recipe (check the food at this time). Then if needed, increase cook time until the desired doneness is obtained.
- Do not cover foods when dry roasting covering will prevent the meat from browning properly.
- When cooking meats use the broiler pan and insert. The broiler pan will catch grease spills and the insert helps prevent grease splatters.

**Table 5: Convection Roasting recommendations** 

Meat		Weight	Oven Temp	Internal Temp	Mins per Ib
Beef	Standing rib roast*	4 to 6 lb.	350°F (177°C)	*160°F (71°C)	25-30
	Rib eye roast*	4 to 6 lb.	350°F (177°C)	*160°F (71°C)	25-30
	Tenderloin roast	2 to 3 lb.	400°F (204°C)	*160°F (71°C)	15-25
Poul- try	Turkey whole**	12 to 16 lb.	325°F (163°C)	180°F (82°C)	8-10
	Turkey whole**	16 to 20 lb	325°F (163°C)	180°F (82°C)	10-15
	Turkey whole**	20 to 24 lb.	325°F (163°C)	180°F (82°C)	12-16
	Chicken	3 to 4 lb.	350°F-375°F (177°C- 191°C)*	180°F (82ºC)	12-16
Pork	Ham roast, fresh	4 to 6 lb.	325°F (163°C)	160°F (71°C)	30-40
	Shoulder blade roast	4 to 6 lb.	325°F (163°C)	160°F (71ºC)	20-30
	Loin	3 to 4 lb.	325°F (163°C)	160°F (71°C)	20-25
	Pre-cooked ham	5 to 7 lb.	325°F (163°C)	160°F (71°C)	30-40

<sup>\*</sup> The U.S. Department of Agriculture states, "Rare fresh beef is popular, but you should know that cooking it to only 140°F (60°C) means some food poisoning organisms may survive." (Source: Safe Food Book, Your Kitchen Guide) The lowest temperature recommended by the USDA is 145°F (63°C) for medium rare fresh beef. For well done 170°F (77°C)\*\* Stuffed turkey requires additional roasting time. Shield legs and breast with foil to prevent over browning and drying of the skin.

#### **Setting Broil**

Use the broil function to cook foods that require direct exposure to radiant heat for optimum browning results. Broiling may produce smoke. If smoke is excessive, place food further away from the heating element.

The broil feature preset to 550°F. Broil may be set at any temperature between 400°F (205°C) and 550°F (288°C).



#### **WARNING**

Should an oven fire occur, close the oven door and turn the oven off. If the fire continues, use a fire extinguisher. Do not put water or flour on the fire. Flour may be explosive and water can cause a grease fire to spread and cause personal injury.



#### **CAUTION**

Always use pot holders or oven mitts when using the oven. When cooking, the oven interior, oven racks, and cooktop will become very hot which can cause burns.



#### **IMPORTANT**


Broiler pans and inserts allow the grease to drain away from the high heat of the broiler. Do not use the pan without the insert. Do not cover the insert with foil - the exposed grease could ignite.

# To set broil with the default broil oven temperature of 550°F (288°C):

- Arrange the oven racks when cool. For optimum browning results, preheat oven for 2 minutes before adding food.
- 2. Select Oven Mode and scroll to Broil.
- 3. Default **550°** appears.
- 4. If lower broil temperature is needed use keypad to select between 400° and 550°.



- 5. Press START. Broil with oven door closed.
- 6. Broil on one side until food is browned; turn and broil other side until done to your satisfaction.
- 7. When finished broiling, press **ON/OFF**.



# 34

# **SETTING OVEN CONTROLS**

#### Important notes:

- Always arrange oven racks when the oven is cool.
- For best results when broiling, use a broil pan with broil pan insert designed to drain the fat from the food and help avoid spatter and reduce smoking.
- When broiling, always pull the oven rack out to the stop position before turning or removing food.

**Table 6: Broil recommendations** 

Food item	Rack Posi-	Temp	Cook time in minutes		Internal Tempera-	Doneness
	tion		1st side	2nd side	ture	
Steak 1" thick	5	550°F (288°C)	4:00	4:00	140°F (60°C)	Rare**
Steak 1" thick	5	550°F (288°C)	6:00	4:00	145°F (63°C)	Medium
Steak 1" thick	5	550°F (288°C)	7:00	5:00	160°F (71°C)	Medi- um-well
Steak 1" thick	5	550°F (288°C)	8:00	6:00	170°F (77°C)	Well
Pork Chops 3/4 "thick	5	550°F (288°C)	12:00	10:00	170°F (77°C)	Well
Chicken - Bone In	5	450°F (232°C)	20:00	10:00	170°F (77°C)	Well
Chicken Boneless	5	450°F (232°C)	8:00	6:00	170°F (77°C)	Well
Fish	5	550°F (288°C)	as dii	rected	170°F (77ºC)	Well
Shrimp	5	550°F (288°C)	as directed		170°F (77ºC)	Well
Hamburger 1" thick	5	550°F (288°C)	9:00	7:00	145°F (63°C)	Medium
Hamburger 1" thick	5	550°F (288°C)	10:00	8:00	170°F (77°C)	Well

The U.S. Department of Agriculture states, \*\*Rare fresh beef is popular, but you should know that cooking it to only 140°F (60°C) means some food poisoning organisms may survive." (Source: Safe Food Book, Your Kitchen Guide, USDA Rev. June 1985.) The lowest temperature recommended by the USDA is 145°F (63°C) for medium rare fresh beef. For well done 170°F (77°C). All cook times shown are after 2 minutes of preheating.

#### **Multi-Racks**


Multi-Rack is for baking on up to two racks while following recommended time and temperature. The oven will make adjustments for best results.

**IMPORTANT**: Be sure to use suggested rack positions before setting oven.

- Follow recipe for time and temp and the oven will make needed adjustments for best performance.
- Fully preheat the oven for best results.
- Pans and pizzas should be pulled to the front of the rack.
- Allow at least 2 inches (5 cm) of space between bakeware for proper air circulation.
- · Leave oven lights off while baking.
- Use flat rack in position 1 and glide rack in position 4.

#### To use Multi-Rack:

- 1. Arrange the oven racks when cool.
- 2. Select Oven Mode and scroll to Multi Racks.
- 3. Touch Multi Racks.
- 4. Default **350°** appears. Set another temperature if desired.
- 5. Touch START.
- 6. Set Cook Time if needed.
- 7. Press **START**.
- 8. When Cook Time ends the oven turns off automatically.
- 9. Cooking has ended and Off will be in display.
- 10. Press **ON/OFF** to return display to show the time of day.



#### **Cooking with Steam**

**Note:** More moisture will be present than during conventional baking or roasting. Moisture could condense on the handle or in the door, and depending on the conditions in your kitchen possibly drip onto the floor.

# **Steam Cooking Tips:**

#### **Oven Positioning**

- Use flat rack in the position in the oven for most foods for Steam Roast.
- Lowest position for poultry.

#### **Preparing**

- Use 2-1/2 cups of water for steam bake and steam roast. If steam functions are frequently used, use distilled water.
- Using water container, pour water slowly onto the bottom of oven cavity while still cool.
- Never add water if the oven is warm.
- Never add water during a Steam Bake or Steam Roast cycle.

#### While in Use

- When using Steam, follow the recipe for preheating, cook time, and cook temperature. If the original recipe did not use steam, reduce the temperature by 25°F (14°C), but not below 325°F (163°C).
- Always start with a cold oven.
- Preheating is not necessary when using steam roast.

#### Cleaning

- With a paper towel lightly soaked in distilled white vinegar, wipe out bottom of oven cavity after the oven is cooled or before each use.
- Use the self clean function to clean heavily soiled areas.
- If residue remains after self clean, pour a thin layer of distilled white vinegar onto the bottom of the oven cavity. Allow to sit for 30 minutes. Wipe out vinegar.

#### **Steam Bake**

Steam creates the best conditions for baking bread on a single rack. Baked goods will have improved browning and texture and is recommended for baking moist and flavorful breads and pastries such as baguettes and croissants.

Use flat rack in position 3 for best results for Steam Bake. Pans should be pulled to the front of the rack.

#### To set Steam Bake:

- 1. Select Oven Modes and scroll to Steam Bake.
- 2. Add  $2^{-1}/_{2}$  cups of water to oven bottom as directed.
- 3. Touch **NEXT** and follow Steam Bake instruction for setting temperature.
- 4. Touch START.
- 5. Set **Cook Time**. (Suggests waiting to set Cook Time until oven preheats.)
- When Cook Time ends oven turns off automatically.
- 7. Cooking has ended and Off will be in display.
- 8. Press **ON/OFF** to return to show the time of day.



# CAUTION

Do not use Steam Bake for cooking at temperatures below 325°F (163°C).



#### **IMPORTANT**

Stand to the side of the oven when opening to allow any steam to escape.



#### NOTE

The cooling fan will run on high during steam cooking.


### **Steam Roast**

Steam creates the best conditions for roasting proteins. Meats will be crisp outside and juicy inside.

Steam Roast is recommended for meat or poultry. Use flat rack in position 1 for best results for Steam Bake.

#### To set Steam Roast:

- Select Oven Modes and scroll to Steam Roast.
- 2. Add  $2^{-1}/_{2}$  cups of water to the bottom of the oven as directed.
- Touch **NEXT** and follow Steam Roast instruction for setting temperature.
- 4. Touch START.
- 5. When Cook Time ends oven turns off automatically.
- 6. Cooking has ended and Off will be in display.
- 7. Press **ON/OFF** to return display to show the time of day.





### CAUTION

Do not use Steam Roast for cooking at temperatures below 325°F (163°C).



### **IMPORTANT**

Stand to the side of the oven when opening to allow any steam to escape.



### NOTE

The cooling fan will run on high during steam cooking.


### **Keep Warm**

Keep Warm should only be used with foods that are already at serving temperatures. Keep warm will keep cooked foods warm and ready for serving after cooking has finished.

Keep warm will keep the oven temperature at 140° F - 200° F (60°C - 93°C).

### To set Keep Warm:


- 1. If needed, arrange oven racks and place cooked food in oven.
- 2. Press Oven Modes and scroll to Keep Warm.
- 3. Touch **Keep Warm**.
- 4. Set desired temperature.
- 5. Press **START**.
- 6. Keep Warm will turn off when canceled.




### **Setting Delay Start**

Delay Start allows a delayed starting time only for Bake, Convection Bake, No Preheat, Convection Roast, Steam Roast, Steam Clean, and Self Clean. Prior to setting a delay start, be sure the time of day is set correctly. The maximum delay for a Delay Start is one hour (12 hours for Self Clean or Steam Clean).

1. Press **ON/OFF** key and touch **Oven Modes**.



- 2. Scroll to **Delay Start** and touch.
- 3. Follow the information on the screen to set delay time, temperature, and cook time.



When the Delay Start time is reached, the oven will turn on and begin cooking. The screen will show the oven temperature.

When Cook Time (if used) ends, **Cooking is over** and **Off** and **OKAY** will appear in the display window, and the oven will shut off automatically.

The oven control will sound tones as a reminder until the **OKAY** is pressed.



### **WARNING**

**Food Poisoning Hazard.** Do not let food sit for more than one hour before or after cooking. Doing so can result in food poisoning or sickness.

### **Self Clean**

A self cleaning oven cleans itself with high temperatures (well above normal cooking temperatures), which vaporizes soils or reduces them to a fine powdered ash you can wipe away afterwards with a damp cloth. This function can be programmed for clean times between 2 and 4 hours.

**Important:** Before starting self clean read all following caution and important statements before starting a self clean cycle.



### **CAUTION**

- Do not leave small children unattended near appliance. During self clean cycle, the outside of the oven can become very hot and cause burns if touched.
- Do not line the oven walls, racks, oven bottom, or any part of the range with aluminum foil. This will cause permanent damage to the oven interior and destroy heat distribution, and will melt to the oven interior.
- Do not force the oven door open. This will damage the automatic door locking system. Use caution when opening the oven door after the self clean cycle ends. The oven may still be very hot and cause burns. To avoid possible burns, stand to side of oven when opening door to allow steam or hot air to escape.
- The health of some birds is extremely sensitive to fumes given off during the self clean cycle of any range. Move birds to a well ventilated room.

#### Important notes:

- Completely remove all oven racks and any accessories from oven cavity to avoid damage to oven racks. If the oven racks are not removed they may discolor.
- Remove all items from the oven and cooktop including cookware, utensils, and any aluminum foil. Aluminum foil will not withstand high temperatures from a self clean cycle and will melt.
- Do not spray oven cleaners or oven protective coatings in or around any part of the oven interior. Clean any soil from the oven frame, the door liner outside the oven door gasket, and the small area at the front center of the oven bottom (page 39). These areas heat sufficiently to burn soil on. Clean using soap and water prior to starting Self Clean.

- Remove any excessive spills. Any spills on the oven bottom should be wiped up and removed before starting a self clean cycle. To clean use hot, soapy water and a cloth. Large spills can cause heavy smoke or fire when subjected to high temperatures.
- Do not allow food spills with high sugar or acid content (such as milk, tomatoes, sauerkraut, fruit juices, or pie fillings) to remain on the surface as they may leave a dull spot even after cleaning.
- Do not clean the oven door gasket. The woven material in the gasket is essential for a good seal. Care should be taken not to rub, damage, or remove the oven door gasket. Doing so could cause damage to the door gasket and compromise the performance of the oven.
- The kitchen area should be well ventilated using an open window, ventilation fan, or exhaust hood during the first self clean cycle. This will help eliminate the normal odors.




Figure 7: Clean around the oven door gasket

- Do not attempt to open the oven door when the OVEN LOCK indicator light is flashing.
   Allow about 15 seconds for the motorized door latch mechanism to completely lock or unlock the oven door.
- When the clean time finishes, the oven door will remain locked until the range has cooled sufficiently. In addition to the clean time that was programmed, you must allow about 1 additional hour for the oven to cool before you will be able to open the oven door.

### To set a self clean cycle:

- 1. Be sure the oven is empty and all oven racks are removed. Remove all items from the oven. Be sure oven door is completely closed.
- 2. Touch Oven Modes and scroll to Self Clean.
- 3. Touch **Self Clean** and select 2 hour, 3 hour, or 4 hour clean time.
- 4. Press **TIMER** to start the self clean cycle.





When the oven is set to run a self-clean cycle, the motor door lock will begin locking the oven door. Do not open the oven door while the lock motor is running or when any locking indicators or displays are showing. The oven door is completely locked in about 15 seconds. Once the oven door has locked, CLEAN will appear in the display indicating self clean has started.

Do not force the oven door open when selfclean is active. This can damage the automatic door-locking system. Use caution when opening the door after self-clean cycle is complete; the oven may still be very hot.

### When the self clean cycle has completed:


- 1. **CLEAN** message will turn off, and Hot will appear in display window. The oven door will remain locked while the oven cools.
- Once the oven has cooled down (about 1 hour) and **Hot** is no longer displayed, the oven door may be opened.
- 3. When the oven interior has completely cooled, wipe away any residue or powdered ash with a damp cloth or paper towel.

41

### **SETTING OVEN CONTROLS**

# Setting Delay Start Self Clean To start a delay self clean with default clean time of 3 hours.

- 1. Press **ON/OFF** key and touch **Oven Modes**.
- 2. Scroll and touch Delay Start.



3. Touch **NEXT** and scroll Oven Modes to **Self Clean**. Follow the information on the screen to set delay time, self clean time.





### If it becomes necessary to stop self clean when active:

- Press OFF.
- If self clean has heated the oven to a high temperature, allow enough time for the oven to cool.
- Before restarting self clean, be sure to read important notes below.

### **Important notes**

- If self clean was active and then interrupted by a power failure or canceled before the oven was thoroughly cleaned, it may be necessary to run another self clean cycle.
- If the oven temperature was high enough when self clean was interrupted the oven control may not allow another self clean cycle to be set for up to 4 hours.

### Steam Clean

The Steam Clean feature offers a chemical free and time saving method to assist in the routine cleaning of small and light soils. For heavier baked on soils use the Self Clean feature.



### CAUTION

Do not add bleach, ammonia, oven cleaner, or any other abrasive household cleaners to the water used for Steam Clean.

Before cleaning any part of the oven, be sure all controls are turned off and the oven is cool. The oven may be hot and can cause burns.

Be sure the oven is level and cool before starting Steam Clean. If the oven temperature is above room temperature a triple beep will be heard and the function will not start. Steam Clean produces best results when started with a cool oven.

### To set a Steam Clean cycle:

- 1. Remove all racks and oven accessories.
- 2. Scrape or wipe loose debris and grease from the oven bottom.
- 3. Pour 1 cup of tap water onto the oven bottom. Close oven door.




Figure 8: Add 1 cups of tap water

- 4. Touch **Oven Modes**, scroll to and touch **Steam** Clean.
- 5. Touch **START**.
- 6. The time the Steam Clean cycle will end is shown in the display. Do not open the door during this time. If door is open while in Steam Clean (d-O) will appear in the display.
- 7. When the steam clean cycle is complete an alert will sound and the Off message will show in the display. Press off to return to the clock.

- 8. Take care opening the door when the steam clean is finished. Stand to the side of the oven out of the way of escaping vapor.
- 9. Wipe oven cavity and bottom. Do not clean oven door gasket. Avoid leaning or resting on the oven door glass while cleaning cavity.



Figure 9: Clean around the oven door gasket

#### **Notes:**

- Opening the oven door during the steam clean cycle prevents the water from reaching the temperature needed to clean.
- For best results, clean oven immediately after the cycle is complete. Steam clean works best for soils on the oven bottom.
- A non-abrasive scouring pad, stainless steel sponge, plastic scraper, or eraser style cleaning pad (without cleaner) can be used for difficult soils. Moisten pads with water before use.
- Place a paper towel or cloth in front of the oven to capture any water that may spill while wiping out.
- Do not leave the residual water in the oven for any length of time.
- Some condensation or water vapor may appear close to the oven vent and the oven door glass. This is normal. The oven gasket may become damp; do not wipe dry.
- Local water sources often contain minerals (hard water). If hard water deposits occur, wipe cavity with a 50/50 solution of water and vinegar or 50/50 solution of lemon juice and water.
- Steam clean cannot be programmed with a delayed start time.
- If Steam Clean results are not satisfactory, run a Self Clean. See "Self Clean" on page 39.

### **Cooking with Food Probe**

Use the probe feature for best results when cooking foods such as roasts, hams, or poultry.

The Food Probe works with the following oven modes: Bake, Convection Bake, Air Fry, Convection Roast, Steam Roast, and Turkey.

The probe feature, when set correctly, will signal an alert when the internal food temperature reaches the desired set target temperature. The probe settings for how the oven behaves should be set first in the oven menu.

When active, the probe displays the internal food temperature which is visible in the display during the cooking process. This eliminates any guesswork or the need to open the oven door to check the thermometer.

For meats like poultry and roasts, using a probe to check internal temperature is the safest method to ensure properly cooked food.

To set Food Probe: Touch Oven Modes, scroll to Food Probe and follow directions on the display.

Connect the food probe before selecting oven mode.

OKAY



### **CAUTION**


Do not use kitchen utensils to pull on the probe cable or handles. Always insert and remove the probe using the provided handles, as shown in and always use a pot holder to protect hands from possible burns.

### Proper placement of probe in food.

Insert the probe so that the probe tip rests inside the center of the thickest part of meat or food. For best results, do not allow the probe temperature sensor to contact bone, fat, gristle, or the cookware.



- For bone-in ham or lamb, insert the probe into the center of lowest large muscle or joint.
- For meat loaf or casseroles, insert the probe into center of food.
- When cooking fish, insert meat probe just above the gill.
- For whole poultry or turkey, fully insert the probe sensor into the thickest part of the breast.



### **Using the Food Probe for Turkey**

- Select Oven Modes and scroll to Food Probe.
- 2. The display will remind you to insert the probe into the turkey and place in oven on rack position 1.
- 3. Display reminds you to connect the food probe to the receptacle before setting oven mode:
- 4. Touch **NEXT**.
- 5. Touch Turkey in Oven Modes.
- Set target food temperature after pressing NEXT.
- 7. Set oven temperature and press **START**.
- 8. When the target temperature of the turkey (internal temperature) is reached, the oven will turn off if set for cooking to stop in the Oven Menu settings.



### Table 7: USDA recommended minimum internal cooking temperatures

Food Type	Internal Temp.
Ground meat and meat mixtures	
Beef, Pork, Veal, Lamb	160°F (71°C)
Turkey, Chicken	165°F (74°C)
Fresh beef, veal, lamb	
Medium rare +	145°F (63°C)
Medium	160°F (71°C)
Well Done	170°F (77°C)
Chicken and Turkey, whole	165°F (74°C)
Poultry Breasts, Roasts	165°F (74°C)
Poultry Thighs, Wings	165°F (74°C)
Stuffing (cooked alone or in bird)	165°F (74°C)
Ham Fresh (raw)	160°F (71°C)
Ham Pre-cooked (to reheat)	140°F (60°C
Eggs dishes	160°F (71°C)
Leftovers and Casseroles	165°F (74°C)

The U.S. Department of Agriculture states, "Rare fresh beef is popular, but you should know that cooking it to only 140°F (60°C) means some food poisoning organisms may survive." (Source: Safe Food Book, Your Kitchen Guide, USDA) Visit the USDA Food Safety and Inspection website at www.fsis.usda.gov

### NOTE

During cooking, the internal food temperature will display in the center of the screen. The oven temperature will be displayed at the bottom of the screen beside the cancel key. To assure accuracy, do not remove the probe from the food or receptacle until the desired internal temperature is reached.

If the probe is removed from the receptacle only, the probe feature will cancel and the oven will turn off. If the probe is removed from the food only, the probe feature will remain active and may eventually generate a probe too hot message.

To change the target (internal food) temperature or the set oven temperature touch the one you want to change and use the + or - to adjust the temperature.

### **→** IMF

### **IMPORTANT**

Do not store the probe inside the oven. Use only the original probe provided. Connecting any other probe or device could result in damage to the oven control, electronics, and the receptacle.

Before starting self clean, double check that the probe is removed from the oven interior. Defrost frozen foods completely before inserting the probe.

# Setting the Sabbath Feature for the Jewish Sabbath and Holidays (some models)



For further assistance, guidelines for proper usage, and a complete list of models with the Sabbath feature, please visit the web at www.star-k. org.

This appliance provides special settings for use when observing the Jewish Sabbath/Holidays. Sabbath mode disables all audible tones or visual display changes on the oven control. Bake is the only cooking feature available while in the Sabbath mode. Most oven controls are locked during Sabbath mode.

To start Sabbath Mode, first select Sabbath from the settings menu. Next, select Delay (if desired), Bake temperature, and cook time (if desired) and set. Cooking will begin after any specified delay.

If cook time was set, once the time has elapsed, the cooking will end and the display will show Idle to indicate that the cook time has ended.

**Important:** The Sabbath mode will override the factory preset 12 hour energy saving mode, and the appliance will stay on until the cooking features are canceled. If cooking is canceled when the appliance is in the Sabbath mode, no audible or visual indicators will be available to verify the cancellation.

If the oven interior lights are needed, be sure to activate them prior to setting the Sabbath mode. Once the oven light is turned on and the Sabbath mode is active, the oven light will remain on until the Sabbath mode is turned off and the oven lights are turned off. The oven door will not activate the interior oven lights when the oven door is opened or closed.

It is recommended that any oven temperature modification made within an active Sabbath mode press the + or - key.

The temperature will increase or decrease with each press by 5°F or 1°C and the change will be accepted automatically.

### A

### WARNING

Food poisoning hazard. Do not let food sit for more than one hour before or after cooking. Doing so can result in food poisoning or sickness. Foods that can easily spoil such as milk, eggs, fish, meat or poultry, should be chilled in the refrigerator first. Even when chilled, they should not stand in the oven for more than 1 hour before cooking begins, and should be removed promptly when finished cooking.


#### Important:

- Do not attempt to activate any other oven function except Bake while the Sabbath feature is active. When the Sabbath feature is active, only the + and - keys and OFF will function. ALL OTHER KEYS should not be used once the Sabbath feature is active.
- You may change the oven temperature once baking has started. Use the + and - keys to raise or lower the oven temperature. Each press of an arrow key will raise or lower the temperature by 5°F (1°C).
- Remember that the oven control will no longer provide audible tones or display any further changes when the Sabbath feature is active.
- The oven will shut-off automatically after completing a bake time and therefore may only be used once during the Sabbath/Jewish Holidays.

### **SETTING SABBATH MODE:**

Sabbath Mode is set using the Menu Options.

- 1. Touch the **Menu Options** bars.
- 2. Scroll to Sabbath Mode.
- 3. Touch **Sabbath Mode** and follow all instructions on screen.



To exit Sabbath Mode, press and hold **EXIT** for three seconds.

Remove spills and any heavy soiling as soon as possible. Regular cleaning will reduce the difficulty of major cleaning later.



### CAUTION

Before cleaning any part of the appliance, be sure all controls are turned off and the appliance is cool.

If ammonia or appliance cleaners are used, they must be removed and the appliance must be thoroughly rinsed before operating. Follow manufacturer's instructions and provide adequate ventilation.




Figure 10: Use cleaners with caution

Surface or Area	Cleaning Recommendation
Aluminum and vinyl	Using a soft cloth, clean with mild dish detergent and water. Rinse with clean water, dry and polish with a soft, clean cloth.
Painted body parts Painted decorative trims	Using a soft cloth, clean with mild dish detergent and water or a 50/50 solution of vinegar and water. Rinse with clean water, dry and polish with a soft, clean cloth. Glass cleaners may be used, but do not apply directly to surface; spray onto cloth and wipe.
Touch display	Using a soft cloth, clean with mild dish detergent and water or a 50/50 solution of vinegar and water. Do not spray liquids directly on the display area. Do not use large amounts of water on the display - excess water may cause damage to the appliance. Do not use other liquid cleaners, abrasive cleaners, scouring pads, or paper towels - they may damage the finish.
Control panel	Using a soft cloth, clean with mild dish detergent and water or a 50/50 solution of vinegar and water. Do not spray liquids directly on the oven control and display area. Do not use large amounts of water on the control panel - excess water on the control area may cause damage to the appliance. Do not use other liquid cleaners, abrasive cleaners, scouring pads, or paper towels - they will damage the finish.
Control knobs	Using a soft cloth, clean with mild dish detergent and water or a 50/50 solution of vinegar and water. To remove control knobs: turn to the OFF position, grasp firmly, and pull off the shaft. To replace knobs after cleaning, line up the OFF markings and push the knobs into place.
Stainless Steel	Using a soft cloth, clean with mild dish detergent and water or a 50/50 solution of vinegar and water. Rinse with clean water, dry with a soft clean cloth. Do not use cleaners containing abrasives, chlorides, chlorine, or ammonia.
Coated Stainless Steel	Using a soft cloth, clean with mild dish detergent and water or a 50/50 solution of vinegar and water. Rinse with clean water, dry with a soft clean cloth. Do not use appliance cleaner, stainless steel cleaner, or cleaner containing abrasives, chlorides, chlorine, or ammonia. These cleaners may damage the finish.

Surface or Area	Cleaning Recommendation
Porcelain-enameled broiler pan and insert Porcelain door liner Porcelain body parts	Rinse with clean water and a damp cloth. Scrub gently with a soapy, non-abrasive scouring pad to remove most spots. Rinse with a 50/50 solution of clean water and ammonia. If necessary, cover difficult spots with an ammonia-soaked paper towel for 30 to 40 minutes. Rinse and wipe dry with a clean cloth. Remove all cleaners or future heating could damage the porcelain. Do not allow food spills with a high sugar or acid content (milk, tomatoes, sauerkraut, fruit juices or pie filling) to remain on porcelain surfaces. These spills may cause a dull spot even after cleaning.
Self-cleaning oven interior	Before setting a self-clean cycle, clean soils from the oven frame, areas outside the oven door gasket, and the small area at the front center of the oven bottom. See "Self Clean" on page 39.
Oven door	Use mild dish detergent and water or a 50/50 solution of vinegar and water to clean the top, sides, and front of the oven door. Rinse well. Glass cleaner may be used on the outside glass of the door. Ceramic smoothtop cleaner or polish may be used on the interior door glass. Do not immerse the door in water. Do not spray or allow water or cleaners to enter the door vents. Do not use oven cleaners, cleaning powders, or any harsh abrasive cleaning materials on the outside of the oven door.
	Do not clean the oven door gasket. The oven door gasket is made of a woven material which is essential for a good seal. Do not rub, dam- age, or remove this gasket.



Figure 11: Do not clean oven door gasket

### **General Cleaning**

Refer to the table at the beginning of this chapter for more information about cleaning specific parts of the oven.

### Follow these cleaning precautions:

- Allow the oven to cool before cleaning.
- Wear rubber gloves when cleaning the appliance manually.

Remove soils using hot, soapy water. Do not allow food spills with a high sugar or acid content (such as milk, tomatoes, sauerkraut, fruit juices or pie filling) to remain on the surface as they may cause a dull spot even after cleaning. Remove spillovers and heavy soiling as soon as possible. Regular cleaning will reduce the effort required for major cleaning later.



### CAUTION

Before manually cleaning any part of the oven, be sure all controls are turned off and the oven is cool. The oven may be hot and can cause burns.

Remove all racks and accessories from the oven before cleaning.

Ammonia must be rinsed before operating the oven. Provide adequate ventilation.

### **Cleaning Porcelain Enamel Oven**

The oven interior is porcelain on steel, it is safe to clean using oven cleaners.

### To remove heavy soil:

- Allow a dish of ammonia to sit in the oven overnight or for several hours with the oven door closed. Clean softened dirt spots using hot, soapy water. Rinse well with water and a clean cloth.
- 2. If soil remains, use a nonabrasive scouring pad or a nonabrasive cleaner. If necessary, use an oven cleaner following manufacturer's instructions. Do not mix ammonia with other cleaners.
- Clean any soil from the oven frame, the door liner outside the oven door gasket and the small area at the front center of the oven bottom. Clean with hot, soapy water. Rinse well using clean water and a cloth.

### **Broiler Pan Cleaning Tips**

To prevent grease from baking on, remove the broiler pan from the oven as soon as cooking is completed. Use oven mitts because the broiler pan is extremely hot. Pour off grease. Soak the pan in hot, soapy water.

Clean the broiler pan as soon as possible after each use. If necessary, use soap-filled steel wool pads. Heavy scouring may scratch the grid.



Figure 12: Broiler pan with insert

# 50 CARE AND CLEANING

### Aluminum Foil, Aluminum Utensils, and Oven Liners

### A

### WARNING

Never cover any slots, holes, or passages in the oven bottom or cover an entire oven rack with materials such as aluminum foil. Doing so blocks air flow through the oven and may cause carbon monoxide poisoning. Aluminum foil linings may trap heat, causing a fire hazard.

- Protective liners—Do not use aluminum foil to line the oven bottom. The high heat of the oven can melt these materials to the oven cavity and ruin the oven. These types of materials can also reduce the effectiveness of the air circulation in the oven and produce poor baking results. Only use aluminum foil as recommended in this manual. Improper installation of these liners may result in risk of electric shock or fire.
- Aluminum utensils The melting point of aluminum is much lower than that of other metals.
   Care must be taken when aluminum pots or pans are used.
- Oven racks Do not use aluminum foil to cover the oven racks. Using a liner in the oven restricts the heat and air flow needed to obtain the best possible cooking results for any oven.

### Replacing the Oven Light



### **CAUTION**

Be sure the oven is unplugged and all parts are cool before replacing the oven light.

The interior oven light is located at the rear of the oven cavity and is covered by a glass shield. The glass shield must be in place whenever the oven is in use.

### To replace the oven interior light bulb:

- 1. Turn electrical power off at the main source or unplug the appliance.
- 2. Remove interior oven light shield by turning a quarter turn counter-clockwise.
- 3. Replace bulb with a new T-4 type Halogen 25 watt appliance bulb.



### NOTE

Wear a cotton glove or use a paper towel when installing a new bulb. Do not touch the new bulb with your fingers when replacing. This will shorten the life of the bulb.

- 4. Replace glass oven light shield by rotating clockwise.
- 5. Turn power back on again at the main source (or plug the appliance back in).
- 6. Be sure to reset the time of day on the clock.




Figure 13: Wall oven Halogen light

### **Caring for Your Glide Racks**


**Caution:** Handle oven racks only when they are cool. After cooking or after the fresh-clean cycle, racks will be very hot and can cause burns.

### **Important Notes:**


- Remove all oven racks, including ladder racks, before starting a clean cycle.
- Do not use cooking oil, cooking spray, or other oil-based lubrication products on the glide rack extension tracks. Use only the graphite lubrication in this area. To order graphite lubrication, contact your installer, servicer or dealer.
- It is important that the parts of the rack that contact the oven sides always have a light coating of vegetable oil. Apply a thin layer of vegetable oil to the sides of the rack after every fresh-clean cycle and when the rack becomes difficult to reposition in the oven.

### To lubricate the glide rack:


- 1. Remove the rack from the oven and place the rack on a large flat surface covered with newspaper or scrap cloth. Fully extend the rack.
- 2. Wipe away debris and crumbs from the glide track using a cloth or sponge.




3. Shake graphite lubrication very well before applying. Apply to loading guides, and rotation pin. Repeat on both sides of the glide rack.




4. Extend and return the glide rack several times along the tracks to distribute the lubrication.



5. Turn the rack upside down and apply graphite lubrication to the insides of the loading guides.



- 6. Extend and return the glide rack several times along the tracks to distribute the lubrication.
- Apply a thin layer of cooking oil to the bottom of the "V" and the glide channels. Keeping the frame sides lightly lubricated allows the entire rack to slide easily when changing rack positions.
- 8. Replace rack in oven right-side up.



### Removing and Replacing the Oven Door



### **CAUTION**

The door is heavy. For safe, temporary storage, lay the door flat with the inside of the door facing down.



### **IMPORTANT**

Special door care instructions - For safe, temporary storage, lay the door flat with the inside of the door facing down.

Most oven doors contain glass that can break. Do not hit the glass with pots, pans, or any other object. Scratching, hitting, jarring, or stressing the glass may weaken its structure, causing an increased risk of breakage at a later time. Do not close the oven door until all of the oven racks are fully in place.



- 1. Open oven door completely, horizontal with floor (Figure 14).
- 2. Pull up the lock located on each hinge support toward front of the oven until the lock stops. You may have to apply a little upward pressure on the lock to pull it up (Figure 15).
- 3. Grasp the door by the sides, and close the door until the door frame makes contact with the unlocked hinges (Figure 16).
- Pull the bottom of the door toward you while rotating the top of the door toward the appliance to completely disengage the hinge levers (Figure 17).

#### To replace the oven door:

- Firmly grasp both sides of oven door along the door sides. Do not use the oven door handle (Figure 17).
- 2. Hold the oven door at the same angle as the removal position (Figure 16) Carefully insert the hinge levers into the oven frame until you feel the hinge levers are seated into the hinge notches. The hinge arms must be fully seated into the hinge notches before the oven door can be fully opened.
- 3. Fully open the oven door, horizontal with floor (Figure 14).
- 4. Push the door hinge locks up toward and into the oven frame on both left and right oven door hinges to the locked position (Figure 15).
- 5. Close the oven door.




Figure 14: Door hinge location




Figure 15: Door hinge lock




Figure 16: Removal position




Figure 17: Remove door

### Oven Baking

For best cooking results, preheat the oven before baking cookies, breads, cakes, pies, pastries, etc. There is no need to preheat the oven for roasting meat or baking casseroles. The cooking times and temperatures needed to bake a product may vary slightly from your previously owned appliance.

Baking Problems and Solutions Baking Problems		
Baking Problems	Causes	Corrections
Cookies and biscuits burn on the bottom.	Cookies and biscuits put into oven before oven is preheated.	Allow oven to preheat to desired temperature before placing food in oven.
	ed.	Choose pan sizes that will permit at least 2" of air space.
Cakes too dark on top or bottom	Cakes put in oven before oven is preheated.	Allow oven to preheat to the selected temperature before placing food in the oven.
	Rack position too high or too	Use proper rack position for baking needs.
	low. Oven too hot	Set oven temperature 25°F (13°C) lower than recommended.
Cakes not done in center	Oven too hot Incorrect pan size.	Set oven temperature 25°F (13°C) lower than recommended.
	Pan not centered in oven.	Use pan size suggested in recipe.
	Glass cookware slow heat conductor.	Use proper rack position and place pan so there are at least 2" (5.1 cm) of space on all sides of pan.
		Reduce temperature and increase cook time or use shiny bakeware.
Cakes not level.	Oven not level.  Pan too close to oven wall or	Place a marked glass measuring cup filled with water on the center of the oven rack. If the water level is uneven, refer to the installation instructions for leveling the oven.
	rack overcrowded. Pan warped. Oven light left on while baking.	Use proper rack position and place pan so there are at
		least 2" (5.1 cm) of space on all sides of pan.
		Do not use pans that are dented or warped.
	<u> </u>	Do not leave the oven light on while baking.
Foods not done when cooking time is	Oven too cool. Oven overcrowded.	Set oven temperature 25°F (13°C) higher than suggested and bake for the recommended time.
over.	Oven door opened too frequently.	Be sure to remove all pans from the oven except the ones to be used for baking.
		Open oven door only after the shortest recommended baking time.

### **BEFORE YOU CALL**

Let us help you troubleshoot your concern! This section will help you with common issues. If you need us, visit our website, chat with an agent, or call us. We may be able to help you avoid a service visit. If you do need service, we can get that started for you!

1-800-374-4432 (United States)

1-800-265-8352 (Canada)

### Frigidaire.com

Frigidaire.ca

Problem	Cause / Solution
Entire appliance does not operate	Appliance not connected. Make sure power cord is plugged properly into outlet. Check your fuse box or breaker box to make sure the circuit is active.
	Electrical power outage. Check house lights to be sure. Call your local electric company for service outage information.

Oven Problems	
Problem	Cause / Solution
Poor baking results.	Many factors affect baking results. Use proper oven rack position. Center food in the oven and space pans to allow air to circulate. Preheat the oven to the set temperature before placing food in the oven. Try adjusting the recipe's recommended temperature or baking time. See "Oven Temperature Calibration" on page 18 if you feel the oven is too hot or too cool.
Flames inside oven or smoking from oven vent	Excessive spills in oven. Grease or food spilled onto the oven bottom or oven cavity. Wipe up excessive spills before starting the oven. If flames or excessive smoke are present when using broil, see "Setting Broil" on page 34.
Oven smokes excessively when broiling.	Incorrect setting. Follow the "Setting Broil" on page 34.
	Meat too close to the broil element or burner. Reposition the broil pan to provide proper clearance between the meat and broil element or burner. Remove excess fat from meat. Cut remaining fatty edges to prevent curling, but do not cut into lean.
	Grease build up on oven surfaces. Regular cleaning is necessary when broiling frequently. Grease or food splatters will cause excessive smoking.
Convection fan does not rotate.	Oven door is open. The convection fan will turn off if the oven door is opened when convection is active. Close the oven door.

### **BEFORE YOU CALL**

Self-Clean Problems	
Problem	Cause / Solution
Self clean does not work.	Oven control not set properly. See "Self Clean" on page 40.
Oven racks discolored or do not slide easily.	Oven racks left in oven cavity during self clean. Remove oven racks from oven cavity before starting a self-clean cycle. Clean by using a mild abrasive cleaner following manufacturer's instructions. Rinse with clean water, dry, and replace in oven.
Soil not completely removed after self clean.	Self clean was interrupted. Review instructions on "Self Clean" on page 40.  Excessive spills on oven bottom. Remove excessive spills before starting self clean.  Failure to clean soil from the oven frame, the door liner outside the oven door gasket, and the small area at the front center of the oven bottom. These areas are not in the self-cleaning area, but get hot enough to burn on residue. Clean these areas before starting the self-cleaning cycle. Burned-on residue can be cleaned with a stiff nylon brush and water or a nylon scrubber. Be careful not to damage the oven gasket.

Other Problems	
Problem	Cause / Solution
Appliance is not level.	Poor installation. Place the oven rack in the center of the oven. Place a level on the oven rack. Adjust the leveling legs at the base of the appliance until the rack is level.
	Kitchen cabinet alignment may make range appear not level. Be sure cabinets are square and have sufficient room for appliance clearance.
Cannot move appliance easily. Appliance must be accessible for service.	Cabinets not square or are built in too tightly. Contact the builder or installer to make the appliance accessible.
Oven light does not work.	Be sure the oven light is secure in the socket. See "Replacing the Oven Light" on page 62.

### 56 WARRANTY

Your appliance is covered by a one year limited warranty. For one year from your original date of purchase, Electrolux will pay all costs for repairing or replacing any parts of this appliance that prove to be defective in materials or workmanship when such appliance is installed, used and maintained in accordance with the provided instructions.

#### **Exclusions**

This warranty does not cover the following:

Products with original serial numbers that have been removed, altered or cannot be readily determined.

Product that has been transferred from its original owner to another party or removed outside the USA or Canada.

Rust on the interior or exterior of the unit.

Products purchased "as-is" are not covered by this warranty.

Food loss due to any refrigerator or freezer failures.

Products used in a commercial setting.

Service calls which do not involve malfunction or defects in materials or workmanship, or for appliances not in ordinary household use or used other than in accordance with the provided instructions.

Service calls to correct the installation of your appliance or to instruct you how to use your appliance.

Expenses for making the appliance accessible for servicing, such as removal of trim, cupboards, shelves, etc., which are not a part of the appliance when it is shipped from the factory.

Service calls to repair or replace appliance light bulbs, air filters, water filters, other consumables, or knobs, handles, or other cosmetic parts.

Surcharges including, but not limited to, any after hour, weekend, or holiday service calls, tolls, ferry trip charges, or mileage expense for service calls to remote areas, including the state of Alaska.

Damages to the finish of appliance or home incurred during installation, including but not limited to floors, cabinets, walls, etc.

Damages caused by: services performed by unauthorized service companies; use of parts other than genuine Electrolux parts or parts obtained from persons other than authorized service companies; or external causes such as abuse, misuse, inadequate power supply, accidents, fires, or acts of God.

### **DISCLAIMER OF IMPLIED WARRANTIES; LIMITATION OF REMEDIES**

CUSTOMER'S SOLE AND EXCLUSIVE REMEDY UNDER THIS LIMITED WARRANTY SHALL BE PRODUCT REPAIR OR REPLACEMENT AS PROVIDED HEREIN. CLAIMS BASED ON IMPLIED WARRANTIES, INCLUDING WARRANTIES OF MERCHANT-ABILITY OR FITNESS FOR A PARTICULAR PURPOSE, ARE LIMITED TO ONE YEAR OR THE SHORTEST PERIOD ALLOWED BY LAW, BUT NOT LESS THAN ONE YEAR. ELECTROLUX SHALL NOT BE LIABLE FOR CONSEQUENTIAL OR INCIDENTAL DAMAGES SUCH AS PROPERTY DAMAGE AND INCIDENTAL EXPENSES RESULTING FROM ANY BREACH OF THIS WRITTEN LIMITED WARRANTY OR ANY IMPLIED WARRANTY. SOME STATES AND PROVINCES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR LIMITATIONS ON THE DURATION OF IMPLIED WARRANTIES, SO THESE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS WRITTEN WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

#### If You Need Service

Keep your receipt, delivery slip, or some other appropriate payment record to establish the warranty period should service be required. If service is performed, it is in your best interest to obtain and keep all receipts. Service under this warranty must be obtained by contacting Electrolux at the addresses or phone numbers below.

This warranty only applies in the USA and Canada. In the USA, your appliance is warranted by Electrolux Major Appliances North America, a division of Electrolux Home Products, Inc. In Canada, your appliance is warranted by Electrolux Canada Corp. Electrolux authorizes no person to change or add to any obligations under this warranty. Obligations for service and parts under this warranty must be performed by Electrolux or an authorized service company. Product features or specifications as described or illustrated are subject to change without notice.

### USA 1-877-435-3827

Electrolux Major Appliances NA 10200 David Taylor Drive Charlotte, NC 28262 ElectroluxAppliances.com



Canada 1.800.265.8352

Electrolux Canada Corp. 5855 Terry Fox Way Mississauga, Ontario, Canada L5V 3E4

ElectroluxAppliances.ca

## FRIGIDAIRE.

# welcome home


Our home is your home. Visit us if you need help with any of these things:



owner support



accessories





registration

(See your regristration card for more information.)

Frigidaire.com 1-800-374-4432

Frigidaire.ca 1-800-265-8352