



Extension Frame Instructions for 5-Burner Gas Cooktop Models

GC5271WTK30

GC5272BTK30

GC527SSTK30

These models include a stainless steel frame (30"W x 20.625"D) that allows your cooktop to fit a countertop cut-out that is up to 30" wide.

To install TK30 models, lay a thin bead of bedding compound along the edge of the cut-out, and then lay the frame over this, pressing down to make a good seal once the frame is centered. The frame should be as flush with the countertop as possible.

Then, follow the installation instructions in your cooktop manual, starting on page 5.

Instructions de cadre d'extension pour modèles à table de cuisson à gaz à 5 brûleurs

GC5271WTK30

GC5272BTK30

GC527SSTK30

Ces modèles comprennent un cadre en acier inoxydable (30 "L x 20,625" P) qui permet à votre table de cuisson de s'adapter à une découpe de comptoir de 30 "de large.

Pour installer les modèles TK30, placez un mince cordon de pâte d'étanchéité le long du bord de la découpe, puis posez le cadre sur celui-ci, en appuyant vers le bas pour obtenir une bonne étanchéité une fois le cadre centré. Le cadre doit être aussi affleurant que possible au comptoir.

Suivez ensuite les instructions d'installation dans le manuel de votre table de cuisson, en commençant à la page 21.