




STAND OWNER'S MANUAL

LG CineBeam Q Stand



Please read the safety information carefully before using this product.

CQS710PB

www.lg.com

Copyright © 2024 LG Electronics Inc. All Rights Reserved.

Accessories


The pictures may differ slightly from the actual product.



Owner's Manual




D Bracket




A Stand Base



E Cable Holder



B Stand Base Lower



C Stand Base Upper

Specifications

Model Name	Width x Depth x Height (mm) (inches)	Weight (kg) (lbs)
CQS710PB	300 x 300 x 635.5 (11.8 x 11.8 x 25)	3.2 (7.0)

Safety Precautions


After reading the user manual, always keep it visible.

WARNING




Do not let children hang on or climb on the stand.

The stand may fall over and cause injury or death.



Do not step on or climb on (the edge of) the stand.

The stand may become deformed, causing malfunction or injury to the feet or toes.



When rotating, moving and handling a product with a projector attached to a stand, hold the top/ bottom of the stand base.

Handling the product by holding the bracket and projector may cause the bracket to become loose and the product to fall, resulting in product damage and potential injury.

 CAUTION

This stand (Model Name: CQS710PB) is an exclusive product for LG Electronics HU710PB-GL projector. Using it with other equipment may cause instability and result in injury.

- Do not install on unstable places such as shaky shelves or sloped surfaces, areas with vibrations, or areas where the product is not fully supported.
 - It may fall or tip over, causing injury or product malfunction.
- Place the product on a hard, flat surface.
 - The product may tip over and cause injury.
- When moving or handling the product attached to the stand, be careful not to damage the product or its appearance.

Precautions Before Installation


- Stand does not include an extension lead. To use the projector power and connected devices on stand, purchase and use an extension lead of an appropriate length.
- If a wireless router is installed on top of the stand, the remote control may not operate normally due to frequency interference caused by the proximity of the projector's internal wireless antenna and the wireless router.
- It is recommended that two or more people assemble the product together.

Model to apply stand


2024 release model: HU710PB*

Assembly Guide


1




2







3




4





9



10

