

CLASSIC REFRIGERATION AND WINE STORAGE

- 1 Touch POWER to turn off the unit.
- 2 Touch and hold POWER for 10 seconds.
- 3 SAb appears on the display.

DESIGNER REFRIGERATION AND WINE STORAGE

- 1 With the unit on, touch ►.
- 2 Touch ⚙️.
- 3 Touch and hold ☆ for three seconds.

PRO REFRIGERATION

- 1 If the automatic display lock is turned on, touch and hold ⏻ for three seconds.
- 2 Tap ⚙️.
- 3 Tap ► twice.
- 4 Touch and hold ☆ for three seconds.

648PRO REFRIGERATION

- 1 Touch POWER to turn off the unit.
- 2 Touch and hold POWER for 10 seconds.
- 3 The unit chimes four times to indicate Sabbath mode is on.

UNDERCOUNTER REFRIGERATION

Note: Sabbath mode is not available on ice machines.

- 1 Touch POWER to turn off the unit.
- 2 Touch and hold POWER for 10 seconds.
- 3 SAb appears on the display.

