



Avanti D110J2P-IS Exploded View Diagram A



Avanti D1 10J2P-IS Exploded View Diagram B



D110J2P-IS Part List

NO.	Code	Part Name	Qty
1	GYJSL82681004E	Door	1
2	GYJSL478F1003C	Door axis press piece up	1
3	GYJSL478F1002C	Door axis press piece down	1
4	GYJSL4781004	Door axis	2
5	GYJYZ4781005	Door hinge	1
6	GYJSL478F1001	Door inner cover	1
7	GYJSL82681003D	Door lock	1
8	GYJXJ4680102	Big seal	1
9	/	/	/
10	GYJDQ4680501	Door switch	1
11	GYJSL4781101B	Door lock base	1
12	GYJWJ82681102	Door lock spring	1
13	GYJSL82681103	Door lock base cover	1
14	GYJDQ4680401B	PTC heating element	1
15	GYJSL4680404	PTC installation rack	2
16	GYJSL4680405	PTC installation box	1
17	GYJDQ4680402A	PTC thermal breaker	1
18	GYJSL4681304	Connecting pole	4
19	GYJDQ4680601B	Ground wire at front seal disc	1
20	GYJCY4680602A	Front seal disc	1
21	GYJXJ4680603	Rubber pad	4
22	GYJDQ4681502A	DOE main PCB	1
23	GYJDQ778ES0305	778ES sensor	1
24	GYJHM4680604A	Front seal disc seal cotton	1
25	GYJDQ4680403K	4kgAVT Wire	1
26	GYJCY4681311	Back cover	1
27	GYJSL4681324	Connector	1
28	GYJSL4681223	Exhaust pipe assembly	1
29	GYJCY4681204	Left hook	1
30	GYJCY4681205	Right hook	1
31	GYJXJ4681202	Back support gasket	2
32	GYJCY4681203	Back support	2
33	GYJWJ4680213	Belt tension wheel bearing	1
34	GYJCY4680209	Belt tension wheel spring	1
35	GYJCY4680210	Belt tension wheel support	1
36	GYJBZ82680106	Window pin	1
37	GYJWJ4680211A	Draw spring for belt tension wheel	1
38	GYJSL4680204	Belt tension wheel	1
39	GYJSL4680205	Motor puller for fan	1
40	GYJWJ4680212B	Motor puller	1
41	GYJCY4681303	Motor fixing board	1
42	GYJDQ4680203	Motor connecting line	1
43	GYJDQ4680202B	Capacitor	1
44	/	/	/
45	GYJCY4680208	Motor support contact blocks	1
46	GYJDQ4680201	Dryer motor	1
47	GYJXJ4680206	Motor vibration proof pad	2
48	GYJCY4680207	Motor supporting board	2
49	GYJDQ4680301	Timer	1
50	GYJSL4880301	Power switch Installation rack	1
51	GYJSL25780301	Timer Installation rack	1
52	GYJDQ4680304A	Single switch	1
53	GYJSL4680310F	Tandem switches cap	1
54	GYJDQ4681301	Power cord	1
55	GYJDQ4680701	Fuse tube	1
56	GYJSL4680103A3	Supporting foot	4
57	GYJYSAVT48801	Control Panel sticker	1
58	GYJYSTY5801	Knob	1
59	GYJHM4681306A	Air inlet filter	1
60	GYJSL4681307	Air inlet cover	1
61	GYJSL4680902B	Filter case	1
62	GYJSL4680903	Filter	1
63	GYJHM4680901A	Filter of inner tub	1
64	GYJSL4680807	Filter base	1
65	GYJCY4680802	Inner tub assembly	1
66	GYJSL4680808	Rotating check block	3
67	GYJBZ4680815	Bearing 608	1
68	GYJCY4680805	Bearing base	1
69	GYJXJ4680814	Poli-v belt	1
70	GYJWJ4680811	Axis set	1
71	GYJSL4680806	Ball bearing fan assembly	1
72	GYJBZ4680815	Bearing 608	1
73	GYJCY4680803	Wind case	1
74	GYJHM4680810	Air exhaust sealing sponge	1
75	GYJSL4680809	Air exhaust	1
76	GYJCY4680804	Supporting beam assembly	1
77	GYJXJ4680813	Plastic cover for thermal breaker	1
78	GYJXJ4680812	Fan belt	1
79	GYJDQ4680801	Air exhaust thermal breaker	1