


GETTING Started

WITH YOUR FRIGIDAIRE MULTI-DOOR REFRIGERATOR



BEFORE YOU START



Before starting your refrigerator

Remove tape and glue residue from surfaces before turning on the refrigerator. Choose a place that is near a grounded electrical outlet, allowing clearances for ease of installation, proper circulation, and plumbing and electrical connections.



Set up your refrigerator

After you remove all of the package materials, clean the inside of your refrigerator before using it. See CARE AND CLEANING in your Use & Care Guide.


YOU'RE IN CONTROL



Your refrigerator controls

Using your refrigerator starts with just pressing the keys on your refrigerator control. Adjust the temperature in small increments, allowing the temperature to stabilize.


GALLERY



1. Quickly freezes food. Deactivates after 12 hours.
2. Quickly chills a drink inside the freezer compartment. Touch the Cold Drink Timer key. Time value can be changed using the +/- buttons.
3. Press and hold for 3 seconds to turn ice maker on/off.
4. Adjusting Temp illuminates when temperatures are changed. Press either the + or - to adjust to desired temperature setting. Unit should stabilize temperatures within 24 hours of installation.
5. Quickly chills food. Deactivates after 6 hours.
6. Replace filter, press and hold for 3 seconds to reset.
7. Replace filter, press and hold for 3 seconds to reset.

PROFESSIONAL

1. Select compartment for temperature change (FREEZER OR REFRIGERATOR). Press either the + or - to adjust to desired temperature setting. Unit should stabilize temperatures within 24 hours of installation.
2. Clear Alerts resets any alarms that are active and illuminated on the display.
3. Freeze Boost activates a faster rate for freezing food. Automatically deactivates after 12 hours.
4. Press to toggle between F & C.
5. For the Ice Maker inside the refrigerator, press and hold for 3 seconds to turn ice maker on/off.
6. Press and hold for 3 seconds to reset to default settings.
7. After replacing filter, press and hold for 3 seconds to reset. Status will reset to GOOD.
8. After replacing filter, press and hold for 3 seconds to reset. Status will reset to GOOD.



REMEMBER

- Always unplug the electrical power cord from the wall outlet before cleaning.
- Do not wash any removable parts in a dishwasher.
- Do not clean glass shelves or covers with warm water when they are cold.

QUICK CARE




A little love goes a long way

Keeping your refrigerator clean maintains its appearance and prevents odor build-up.



Be gentle

Clean with warm water and mild soap. For stainless steel models only, use Frigidaire ReadyClean™ Stainless Steel Cleaner.




Make room

If the refrigerator is placed with the door hinge side against a wall, allow additional space so the door can be opened wider.



Air ports

Food placed within 1 inch in front of the air ports may cause food to freeze. See CONTROLS AND SETTINGS in your Use & Care Guide.



FAQs

How do I know which water filter I need for my refrigerator?

When it comes to your water filter, compatible isn't comparable. Frigidaire Genuine filters offer 3 levels of carbon filtration that trap sediment, chemicals, and harmful impurities. Frigidaire filters are NSF certified, the gold standard in water filtration. Compatible or look-alike filters aren't guaranteed to offer the same water quality.

It's always important to use the same filter type that is currently in your refrigerator. Most Owner's Manuals will provide you the water filter information specific to your model.

Why does my refrigerator run most of the time? Is this normal?

Today's refrigerators are designed to be more energy efficient than previous models. This means that they run longer cycles, or run continuously, to maintain an even temperature inside. Please note: starting a unit takes about 10 times as much energy as it does to keep it running.




For more information refer to **TROUBLESHOOTING** in the back of your Use & Care Guide.

LET'S MAKE IT OFFICIAL!

Take the first step to becoming a part of the Frigidaire family by registering your new Multi-Door Refrigerator.

Look for the PhotoregisterSM icon on your registration card.



WE ARE
here
FOR YOU



Have a question?



Want help?



Need service?

frigidaire.com/1 (800) 374-4432

frigidaire.ca/1 (800) 265-8352

owner support

