


USER GUIDE

Parts



VCDE224-SSG3A		
1	ANTI TIP BRACKET	80-54221-00
2	BACK PANEL	80-55350-05
3	CASTER, 3" NON-LOCKING	80-55674-00
4	CASTER, 3" LOCKING	80-55674-01
5	COMPRESSOR ASSEMBLY	80-55548-00
6	CONDENSER ASSEMBLY	80-55453-00
7	CONDENSER FAN	80-54014-00
8	CONTROL ASSEMBLY	80-55552-00
9	DOOR ASSEMBLY	80-55560-02
10	DRAIN PAN	80-54524-00
11	DRAIN TROUGH	80-55484-00
12	DRIER	80-54055-00
13	EVAPORATOR ASSEMBLY	80-55486-00
14	EVAP FAN & COVER	80-54151-03
15	GASKET, DOOR	80-54213-00
16	GRILLE ASSEMBLY	80-55555-02
17	HINGE ASSEMBLY	80-55556-00
18	MAIN BOARD	80-55507-00
19	PACKAGING *	80-55557-00
20	POWER CORD, EXTERNAL *	80-55278-00
21	POWER CORD, INTERNAL *	80-55553-00
22	THERMISTOR	80-54006-00
23	WIRE HARNESS *	80-55402-00

* NOT PICTURED