

Manufactured by
Innovasource, LLC for
Electrolux Home Products, Inc.

Probiotic Dishwasher Cleaner

<u>Ingredient</u>	<u>CAS</u>	<u>Function</u>	<u>Additional Information</u>	<u>Links to Designated Lists</u>
Water	7732-18-5	Diluent	None	
Surfactant	Withheld	Surfactant - Detergent	None	
Polysorbate 80	9005-65-6	Fragrance Solubilizer	None	
Tetrasodium Glutamate Diacetate	51981-21-6	Chelating Agent	None	
Bacillus Cultures	68528-99-0	Odor Control	None	
Citric Acid	77-92-9	Buffering Agent	None	
Sodium Citrate	6132-04-3	Buffering Agent	None	
Fragrance	Withheld	Fragrance Ingredient	None	
Chloromethylisothiazolinone	26172-55-4	Preservative	None	
Methylisothiazolinone	2682-20-4	Preservative	None	
Limonene	5989-27-5	Fragrance Ingredient	Fragrance Allergen	List **
Sodium Hydroxide	1310-73-2	Nonfunctional Constituent	Designated Chemical	List 20

Date of Manufacture: Represented on each product with a Julian Date Code
 Product Safety Data Sheet: [Link to SDS](#)
 Customer Service: Call 1-800-896-9756
 Email: <https://www.electroluxappliances.com/Owner-Support/Contact-Us/>