

98UM5K-B

110UM5K-B

ENGLISH Quick Setup Guide




Please read this manual carefully before operating your set and retain it for future reference.

FRANÇAIS Guide de configuration rapide

Veuillez lire le présent manuel attentivement avant d'utiliser l'appareil et conservez-le pour pouvoir vous y reporter ultérieurement.

ESPAÑOL Guía de instalación rápida

Lea atentamente este manual antes de poner en funcionamiento el equipo y consérvelo para futuras consultas.




ENGLISH

Due to the environment regulations about importation and disposal of batteries, remote control batteries will not be provided with LG monitor signage / commercial TV models (Argentina and Colombia).

ESPAÑOL

Por regulaciones de tipo ambiental respecto a la importación y destrucción de baterías, LG monitor signage / commercial TVs no van a traer incluidas las pilas del control remoto (Argentina y Colombia).



- www.lg.com/id-manual
- SuperSign : <http://partner.lge.com>





ENGLISH

Model Name	Size (Width x Height x Depth) (mm)	Weight (kg)
98UM5K-B	2,198 x 1,253 x 79.5	78
110UM5K-B	2,474 x 1,408 x 99	80

FRANÇAIS

Nom du modèle	Dimensions (largeur x hauteur x épaisseur) (mm)	Poids (kg)
98UM5K-B	2 198 x 1 253 x 79,5	78
110UM5K-B	2 474 x 1 408 x 99	80

ESPAÑOL

Nombre del modelo	Tamaño (ancho x alto x grosor) (mm)	Peso (kg)
98UM5K-B	2 198 x 1 253 x 79,5	78
110UM5K-B	2 474 x 1 408 x 99	80

Modelo	Alimentación
98UM5K-B	100-240 V~ 50/60 Hz 5,8 A
110UM5K-B	100-240 V~ 50/60 Hz 6,0 A



* M F L 7 1 9 8 4 7 0 3 *

(2303-REV00)

