

RM16J0W / RM16J1B Parts List

No.	Descriptions	Qty	Parts No.
1	foam door(RM16J0W-WHITE)	1	501001
	foam door(RM16J1B-BLACK)	1	502001
2	door seal(RM16J0W-WHITE)	1	501002
	door seal(RM16J1B-BLACK)	1	502002
3	door cabinet	1	500003
4	drip tray	1	500004
5	wire shelf	1	500005
6	evaporator door	1	500006
7	evaporator	1	500007
8	thermostat box	1	500008
9	thermostat ass'y	1	500009
10	right leg(RM16J0W-WHITE)	1	501010
	right leg(RM16J1B-BLACK)	1	502010
11	down side bar	1	500011
12	condensor	1	500012
13	up hinge cover(RM16J0W-WHITE)	1	501013
	up hinge cover(RM16J1B-BLACK)	1	502013
14	up hinge	1	500014
15	down hinge	1	500015
16	back plate	1	500016
17	body(RM16J0W-WHITE)	1	501017
	body(RM16J1B-BLACK)	1	502017
18	base plate	1	500018
19	adjustable leg(RM16J0W-WHITE)	1	501019
	adjustable leg(RM16J1B-BLACK)	1	502019
20	wire clamp	1	500020
21	compressor fixed plate	1	500021
22	inside cabinet	1	500022
23	compressor	1	500023
24	protector of compressor	1	500024
25	starter of compressor	1	500025
26	dry filters	1	500026
27	power code(RM16J0W-WHITE)	1	501027
	power code(RM16J1B-BLACK)	1	502027
28	joint wire	1	500028
29	screw	4	500029
30	door safety guards	3	500030

