




BCA306SS-IS EXPLOSIVE VIEW AND PART LIST

Item	Part code	Spare part name	QTY
1	1. 01. 014. 000027	Door	1
2	1. 3. 040100	Control PCB	1
3	2. 02. 011. 100023	Copper hinge	1
4	1. 02. 002. 200303	Door back cover	1
5	1. 02. 005. 200060	Door gasket	1
6	1. 01. 012. 200106	Upper shelf	2
7	1. 02. 010. 900014	Light cover	1
8	2. 04. 002. 000021	Light	1
9	3. 22. 085. 210005	Cabinet	1
10	1. 02. 008. 200041	Copper hinge cover	1
11	1. 02. 013. 200089	Water drip tray	1
12-15	1. 10. 007. 000014	Compressor assembly	1
16	1. 03. 004. 200011	Power line	1
17	1. 02. 013. 000169	Wire clip	1
18	1. 01. 017. 000004	Compressor base	1
19	1. 03. 008. 000064	Wire for compressor	1
20	2. 01. 012. 000019	Thermostat back panel	1
21	1. 03. 001. 000040	Power supply board	1
22	1. 02. 013. 200062	Cover of power board	1
23	1. 06. 002. 100016	Adjusting leveling legs	3
24	2. 02. 011. 100013	Bottom hinge	
25	2. 03. 005. 200002	Front leg	1
26	1. 02. 010. 200022	Sensor cover	1
27	1. 10. 009. 200013	Evaporator	1
28	1. 01. 012. 200107	lower shelf	1
29	1. 01. 012. 200108	Bottom bar	1
30	1. 03. 008. 000087	Connecting wire	1
31	1. 8. 035100	Handle	1