


PRR24C01AS-OD

Presrv™ Outdoor Refrigerator

ZEPHYR



PRR24C01AS-OD

Ref #	Part #	Description	Qty.
1	56300003	Dryer Filter	1
2	11030137	Power Cord	1
3	56220051	Anti Vibration Gasket	1
4	56130035	Drip Tray	1
5	12160006	Compressor	1
5-1	11050026	Compressor Starter	1
5-2	11050027	Compressor Relay	1
6	11030119	Compressor Ground Wire	1
7	50330010	Sealing Tube	1
8	56200105	Control Board Box	1
9	11010173	Main Power Control Board	1
10	11010110	Display Control Board	1
12	56210118	Decorative Hole Cover	3
13	54180068	Upper Right Hinge	1
14	54240019	Evaporator	1
15	56180015	Evaporator Foam	1
16	12130032	Fan Assembly	1
17	54170034	Air Duct Board	1
18	54210039	Fan Cover	1
19	12010012	LED Light	5
20	52150014	LED Light Cover	5
21	56200126	Display Control Box	1
22	52050032	Display Decal	1
23	54190056	Door Axis Plate, Right	1
24	54220011	Door Magnet	1
25	50180005	Locking Hook Plate	1
26	50230035	Door	1
26-1	50280010	Door Handle	1

26-2	56220057	Door Gasket	1
27	50150064	Bottom Door Shelf	1
28	50150065	Door Shelf	4
29	50150066	Glass Shelf	3
30	54140356	Shelf Holding Bracket	2
31	Z0F-C014	Carbon Filter	1
32	54210040	Sensor Cover	1
33	11050008	Temperature Sensor	1
34	11050007	Temperature Sensor	1
35	50260022	Kick Plate	1
36	11040033	Door Switch	1
37	50180006	Door Lock	1
38	54180069	Lower Right Hinge	1
39	50350008	Leveling Leg	4
40	54140284	Cabinet Support Bracket	1
41	54180070	Lower Left Hinge	1
42	54270001	Condensor	1
43	54210041	Condensor Cover	1
44	50330017	Capillary Tube	1
45	12130032	Fan Assembly	1
46	54190058	Compressor Support Plate	1
47	50330020	Connecting Pipe	1
48	50330034	Exhaust Water Pipe	1
49	56210094	Compressor Cover	1
50	01020067	Screw, M4*12	7
51	54180071	Upper Left Hinge	1
52	56210118	Decorative Hole Cover	7
53	54190057	Door Axis Plate, Left	1
54	01020052	Screw, M5*12	2
55	50160013	Door Axis Cap	2
56	15000019	Door Lock Key	1