


USER GUIDE

Parts



VCWC518-SG33A		
Item	Description	Service P/N
1	ANTI TIP BRACKET W/SCREWS *	80-54221-00
2	BACK PANEL, 518 NSF	80-55474-01
3	COMPRESSOR ASSEMBLY, 5 CLASS	80-55452-00
4	CONDENSER ASSY 5 CLASS	80-55453-00
5	CONDENSER FAN W/SCREWS	80-54014-00
6	DOOR ASSY, 518-GS-NSF	90-17033-00
7	DRAIN PAN	80-54217-00
8	DRAIN TROUGH 5 CLASS 18"	80-55476-00
9	DRIER	80-54055-00
10	ENCLOSURE ASSEMBLY, BOARD	80-54532-00
11	EVAP ASSY, 5 CLASS 18"	80-55478-00
12	EVAP SS COVER 18", COM	80-55561-07
13	EVAPORATOR FAN	80-54807-00
14	EVAPORATOR FAN COVER W/SCREWS	80-54809-00
15	GASKET, DOOR 18" NSF	80-55656-04
16	GRILLE, 18" 5 CLASS	80-55479-00
17	HINGE ASSEMBLY, NSF	80-55374-02
18	LADDERS, 2 SHELVING FRONT 5CL	80-55613-05
19	LADDERS, 2 SHELVING REAR 5CL	80-55613-04
20	LEG LEVELERS (4) 3/8"-16	80-54019-01
21	LIGHT ASM, 2 COLOR	80-55272-00
22	MAIN BRD/DISPLAY ASSY	80-55429-01
23	PACKAGING *	80-54145-00
24	PLUNGER SWITCH, NUGGET	80-55375-00
25	POWER CORD, EXTERNAL *	80-55362-00
26	ROCKER SWITCH	80-55603-00
27	SERIAL INVERTER 120V (FMX)	80-55570-00
28	SLIDE ASSY, 5 CLASS	80-55509-00
29	THERMISTOR ASSY	80-55225-00
30	WINE RACK FRONT 18" 5 CLASS	80-55501-00
31	WINE RACK, 518	80-33067-05
32	WIRE HARNESS, HI VOLTAGE *	80-55592-01
33	WIRE HARNESS, LOW VOLTAGE *	80-55592-00

* NOT PICTURED