

U-CHILL[®]



GETTING STARTED

COOL TO THE LAST DROP

U-Chill is designed to maintain the temperature of chilled wine, craft beer bomber bottles, carafes, and more.

Here's how...



TOUCH & SERVE


ON

Tap any part of the Crown with your finger.

The light will turn on
and within seconds U-Chill will
be cold and ready for a chilled bottle.

OFF

Hold your finger on the Crown
until the light turns off. This should
take 2 seconds.



CHOOSE YOUR COLOR

Once on, tap 3 times on the Crown.

After the flash, **keep tapping**
to browse through the colors.

Once you find the one you like,
simply stop tapping to set the color.

To change color, repeat this process.

U-CHILL

U-Chill maintains the temperature of your chilled bottle within 2°F to 4°F of opening temperature.

If your beverage is at 41°F, place it in U-Chill and it will stay at 41°F.

If your beverage is 50°F, U-Chill will keep it at 50°F.



U-CHILL PLUS

U-Chill Plus models have 2 additional modes.

U-Chill will always start in standard chill mode.
To change your mode, **hold your finger on the Crown and release** when the light changes to your desired mode:

MODE	TEMP
Off	
Red Wine	Keeps reds at their ideal temperature.
Boost Mode	30 minutes of rapid chilling, then returns to standard chill mode.
Standard Chill	Holds within 2°F to 4°F.



CHECK YOURSELF

U-CHILL PLUS

Once you've selected your mode, the color will always return to your selected lighting color.

**To check which mode you're in,
tap once on the Crown.**

The flash of color will let you know
which mode is activated.

FAQ

HOW DOES IT WORK?

U-Chill uses patented technology to maintain the temperature of your bottle.

When you remove a bottle from your refrigerator and pour a glass, U-Chill will keep your bottle to within 2 to 4 degrees of that temperature, for up to 4 hours.

DOES IT CHILL A ROOM-TEMPERATURE BOTTLE?

U-Chill is designed to maintain the temperature of a bottle.

However, if your bottle isn't quite cold enough, select Boost Mode. After 30 minutes, it will automatically go back to standard chill mode to maintain the new temperature. This is available on U-Chill Plus only.

CAN I ADJUST THE TEMPERATURE?

Because U-Chill creates a cold jacket that insulates the bottle and maintains the temperature, there is no need to set a temperature.

ACTIVATE YOUR
2-YEAR WARRANTY

Register your U-Chill at u-line.com

Or scan below:



LET'S CONNECT

#uchill

@ulinecorp

u-line.com/u-chill



U-Chill powered by **KAELO**