




BCT115J1B-IS Spare Part Lists

No.	Part No.	Part name	Qty
1	300003543	panel component	1
2	501001494	heating plate 1800W	1
3	501001493	heating plate 1200W	1
4	505050001	bracket A	6
5	501001482	control pcb	1
6	501001401	power pcb	1
7	305060222	bottom shell	1
8	503150095	silicone strip	1
9	305060113	thermal shelves 1	1
10	305060150	thermal shelves 2	1
11	503150039	silicone strip	1
12	503110028	Hexagonal column - control PCB	5
13	503000001	power cable buckle	1
14	501001432	power cable	1
15	503150013	Sealing ring	4
16	503110014	Installing column	4
17	506000006	Mica slice	1
18	501001495	wire L=600	1
19	501001496	wire L=350	1