




WBC16Z1B-IS

#	Part Name	Part#	qty
2	upper door hinge cover	SC70004A10	1
3	upper door hinge	SC70004010	1
4	upper wave shelf	SC70009010	1
5	upper flat shelf	SC70Z09006	1
6	bottom flat shelf	SC46009006	1
7	evaporator	SC46005001	1
8	evaporator fix plate1	SC13005005	2
9	wine rack	SC46009008	1
10	evaporator fix plate2	SC13005006	2
11	door gasket clipping strip	SC46EA4017	1
12	controller panel	SC20006A01	1
14	controller panel fix plate	SC46EA4018	1
13	controller panel connect wire	SC46EA6005	1
15	glass door	SC46EA4002	1
16	door stopper	SC46EA4014	1
17	door gasket	SC46004003	1
18	lower front castor	SC46005A37	1
19	bottom door hinge	SC98B04011	1
20	sensor headgear	SC46RG5005	1
21	sensor headgear pin	SC46RG50A5	2
22	front feet	SC46005037	1
23	Compressor connecting wire	SC46EA6008	1
24	power cable	BC46EX6B06	1
25	compressor installation plate	SC46005017	1
26	compressor	SC46005A18	1
27	dryer filter	SC13005029	1
28	compressor drip tray	SC13005025	1
29	power panel cover	BC46EX6003	1
30	power panel	SC46EA6003	1
31	power panel base	BC46EX6002	1
32	upper hinge hole cover	SC13004B10	1