

SIMPLE MANUAL

Portable Bluetooth

XL9T



Copyright © 2023-2024 LG Electronics Inc. All Rights Reserved.

Limited Warranty - USA

ARRITRATION NOTICE: THIS LIMITED WARRANTY CONTAINS AN ARRITRATION PROVISION THAT REOLIRES YOU AND LG ELECTRONICS ("LG") TO RESOLVE DISPUTES BY BINDING ARBITRATION INSTEAD OF IN COURT, UNLESS YOU CHOOSE TO OPT OUT, IN ARBITRATION, CLASS ACTIONS AND JURY TRIALS ARE NOT PERMITTED. PLEASE SEE THE SECTION TITLED "PROCEDURE FOR RESOLVING DISPUTES" BELOW.

Should your LG Portable Bluetooth Speaker ("Product") fail due to a defect in material or workmanship under normal use, during the warranty period ("Warranty Period") set forth below, LG will, at its option either repair or replace the Product upon receipt of original Proof of Purchase ("POP"). This limited warranty is valid only to the original retail purchaser of the Product ("Customer" or "You") and applies only when purchased and used within the continental United States, Alaska, Hawaii, and U.S. Territories.

WARRANTY PERIOD	HOW SERVICE IS HANDLED
Parts and Labor: One (1) Year from date of delivery of Original Purchase (Internal/functional parts only)	The original sales invoice and delivery receipt* specifying the Product and date of purchase and delivery is required to obtain warranty service.
	For any service-related inquiries, including troubleshooting assistance, visit www.lg.com or call 1-800-243-0000, or write to: ATTN: LG Customer Interactive Center 201 James Record Road SW Huntsville, Alabama 35824
	Shipping Costs In-bound and out-bound shipping will be paid by LG during the Warranty Period.

- Repaired or Replacement Products and parts are warranted for the remaining portion of the original warranty period or ninety (90) days, whichever is greater.
- Replacement Products and parts may be new, reconditioned, refurbished, or otherwise factory remanufactured.
- Replaced Product or part(s) will be the property of LG.
- If the original date of purchase cannot be verified, the warranty will begin on the 1st day of the manufacture month.

Disclaimer:

EXCEPT TO THE EXTENT PROHIBITED BY APPLICABLE LAW. ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS. FOR A PARTICULAR PURPOSE ON THE PRODUCT IS LIMITED IN DURATION TO THE DURATION OF THE ABOVE LIMITED WARRANTY UNDER NO CIRCUMSTANCE SHALL IG BE LIABLE FOR ANY INCIDENTAL SPECIAL OR CONSEQUENTIAL DAMAGES INCLUDING. WITHOUT LIMITATION. LOST GOODWILL. LOST REVENUE OR PROFITS. WORK STOPPAGE. PRODUCT FAILURE, IMPAIRMENT OF OTHER GOODS, LOSS OR CORRUPTION OF PROGRAMMING OR DATA, LOSS OF USE, INJURY TO PERSONS OR PROPERTY ARISING OUT OF OR RELATED TO THE PRODUCT, LG'S TOTAL LIABILITY IF ANY DAMAGES OR OTHERWISE, SHALL NOT EXCEED THE INVOICE VALUE PAID BY YOU FOR THE PRODUCT FURNISHED, WHICH IS THE SUBJECT OF A CLAIM OR DISPUTE.

SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, OR ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU. THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY ALSO HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

THIS LIMITED WARRANTY DOES NOT APPLY TO:

- Service trips to deliver, pick up, install, educate on how to operate, correct wiring or for unauthorized repairs.
- Damage or failure of the Product caused by power failures, interruptions, or inadequate electrical service.
- Damage or failure resulting from operating or using the Product in any way contrary to the instructions, use other than the Product's intended purpose, or use in conditions contrary to those recommended or outlined in the Product's Owner's Manual.
- Damage or failure of the Product caused by transportation and/or handling, including scratches, dents, chips, and/or other damage to the finish of your Product, unless such damage results from a defect in materials or workmanship and is reported within one (1) week of delivery (Call: 1-800-243-0000)
- Damage or failure resulting from improper installation, repair, maintenance, or foreign objects placed in or connected to the Product, Improper repair includes use of parts not approved or specified by LG.
- Damage or failure caused by unauthorized modification, alteration, adjustment of user controls, calibration, accessories, or separate system components, or due to use with incompatible mobile devices.
- Damage or failure caused by any accessories and software not approved or specified by LG.
- Damage or failure caused by reception problems due to inadequate home antenna or faulty antenna connections, or computer
- Damage or failure caused by incorrect electrical current, voltage, components or consumable cleaning products that are not approved by LG.

- Damage or failure of any display, open box, discounted, or refurbished Product.
- Damage (including cosmetic damage), deterioration, malfunction, loss or personal injury due to misuse, abuse, negligence, improper maintenance or storage, or acts of nature or other causes beyond LG's control, (Causes beyond LG's control include, but are not limited to, pests or vermin, lightning strike, wind, fire, power surges, water damage, or flood.)
- Products used for other than normal and proper household use (e.g., rental, commercial or industrial use, offices, or recreational facilities) or contrary to the Product owner's manual.
- Product with original serial numbers that have been removed, altered, or cannot be readily determined.
- Increases in utility costs and additional utility expenses.
- Products sold "AS IS," "With All Faults," or with a similar disclaimer.
- Any consumable parts such as batteries.

The cost of repair or replacement under the above-mentioned excluded circumstances shall be borne by You.

ARBITRATION PROCEDURE FOR RESOLVING DISPUTES

ALL DISPUTES BETWEEN YOU AND LG ARISING OUT OF OR RELATING IN ANY WAY TO THIS LIMITED WARRANTY OR THE PRODUCT SHALL BE RESOLVED EXCLUSIVELY THROUGH BINDING ARBITRATION. AND NOT IN A COURT OF GENERAL JURISDICTION, BINDING ARBITRATION MEANS THAT YOU AND LG ARE EACH WAIVING THE RIGHT TO A JURY TRIAL AND TO BRING OR PARTICIPATE IN A CLASS ACTION.

Definitions. For the purposes of this section, references to "LG" mean LG Electronics U.S.A., Inc., its parents, subsidiaries and affiliates, and each of their officers, directors, employees, agents, beneficiaries, predecessors in interest, successors, assigns and suppliers; references to "dispute" or "claim" shall include any dispute, claim or controversy of any kind whatsoever (whether based in contract, tort, statute, regulation, ordinance, fraud, misrepresentation or any other legal or equitable theory) arising out of or relating in any way to the sale, condition or performance of the product or this Limited Warranty.

Notice of Dispute. In the event you intend to commence an arbitration proceeding, you must first notify LG in writing at least 30 days in advance of initiating the arbitration by sending a letter to LG at LG Electronics, USA, Inc. Attn: Legal Department-Arbitration 111 Sylvan Avenue, Englewood Cliffs, NJ 07632. You and LG agree to engage in good faith discussions in an attempt to amicably resolve your claim. The notice must provide your name, address, and telephone number, identify the product that is the subject of the claim, and describe the nature of the claim and the relief being sought. If you and LG are unable to resolve the dispute within 30 days, either party may proceed to file a claim for arbitration.

Agreement to Binding Arbitration and Class Action Waiver. Upon failure to resolve the dispute during the 30-day period after sending written notice to LG, you and LG agree to resolve any claims between us only by binding arbitration on an individual basis, unless you opt out as provided below. Any dispute between you and LG shall not be combined or consolidated with a dispute involving any other person's or entity's product or claim. More specifically, without limitation of the foregoing, any dispute between you and LG shall not under any circumstances proceed as part of a class or representative action. Instead of arbitration, either party may bring an individual action in small claims court, but that small claims court action may not be brought on a class or representative basis.

Arbitration Rules and Procedures. To begin arbitration of a claim, either you or LG must make a written demand for arbitration. The arbitration will be administered by the American Arbitration Association ("AAA") and will be conducted before a single arbitrator under the AAA's Consumer Arbitration Rules that are in effect at the time the arbitration is initiated (referred to as the "AAA Rules") and under the procedures set forth in this section. The AAA Rules are available online at www.adr.org/consumer. Send a copy of your written demand for arbitration, as well as a copy of this provision, to the AAA in the manner described in the AAA Rules. You must also send a copy of your written demand to LG at LG Electronics, USA, Inc. Attn: Legal Department-Arbitration 111 Sylvan Avenue, Englewood Cliffs, NJ 07632. If there is a conflict between the AAA Rules and the rules set forth in this section, the rules set forth in this section will govern. This arbitration provision is governed by the Federal Arbitration Act, Judgment may be entered on the arbitrator's award in any court of competent jurisdiction. All issues are for the arbitrator to decide, except issues relating to the scope and enforceability of the arbitration provision and to the arbitrability of the dispute are for the court to decide. The arbitrator is bound by the terms of this provision.


Governing Law. The law of the state of your residence shall govern this Limited Warranty and any disputes between us except to the extent that such law is preempted by or inconsistent with applicable federal law.

Fees/Costs. You do not need to pay any fee to begin an arbitration. Upon receipt of your written demand for arbitration, LG will promptly pay all arbitration filing fees to the AAA unless you seek more than \$25,000 in damages, in which case the payment of these fees will be governed by the AAA Rules, Except as otherwise provided for herein, LG will pay all AAA filing, administration, and arbitrator fees for any arbitration initiated in accordance with the AAA Rules and this arbitration provision. If You prevail in the arbitration, LG will pay your attorneys' fees and expenses as long as they are reasonable, by considering factors including, but not limited to, the purchase amount and claim amount. Notwithstanding the foregoing, if applicable law allows for an award of reasonable attorneys' fees and expenses, an arbitrator can award them to the same extent that a court would. If the arbitrator finds either the substance of your claim or the relief sought in the demand is frivolous or brought for an improper purpose (as measured by the standards set forth in Federal Rule of Civil Procedure 11(b)), then the payment of all arbitration fees will be governed by the AAA Rules. In such a situation, you agree to reimburse LG for all monies previously disbursed by it that are otherwise your obligation to pay under the AAA Rules. Except as otherwise provided for, LG waives any rights it may have to seek attorneys' fees and expenses from you if LG prevails in the arbitration.

Hearings and Location. If your claim is for \$25,000 or less, you may choose to have the arbitration conducted solely on the basis of (1) documents submitted to the arbitrator (2) through a telephonic hearing or (3) by an in-person hearing as established by the AAA Rules, If your claim exceeds \$25,000, the right to a hearing will be determined by the AAA Rules, Any in-person arbitration hearings will be held at a location within the federal judicial district in which you reside unless we both agree to another location


Opt Out, You may opt out of this dispute resolution procedure, If you opt out, neither you nor LG can require the other to participate in an arbitration proceeding. To opt out, you must send notice to LG no later than 30 calendar days from the delivery/ pick-up date of your purchase of the Product by either: (i) sending an e-mail to optout@lge.com, with the subject line: "Arbitration Opt Out" or (ii) calling 1- 800-980-2973. You must include in the opt out e-mail or provide by telephone: (a) your name and address; (b) the date on which the product was delivered or picked up; (c) the product model name or model number; and (d) the

You may only opt out of the dispute resolution procedure in the manner described above (that is, by e-mail or telephone); no other form of notice will be effective to opt out of this dispute resolution procedure. Opting out of this dispute resolution procedure will not affect the coverage of the Limited Warranty in any way, and you will continue to enjoy the full benefits of the Limited Warranty. If you keep this Product and do not opt out, then you accept all terms and conditions of the arbitration provision described above.



XL9T.DUSALLK_SIMPLE_MFL72017135 (sheet).indd 1-5





LG Customer Information Center

1-800-243-0000 1-888-865-3026

USA. Consumer USA, Commercial

Register your product Online!

www.lg.com

Printed in China

ENGLISH Installing and Using the Product

Please read this manual carefully before operating your set and retain it for future reference. To view the instructions of advanced features, visit http://www.lg.com or scan QR code and then download Owner's Manual. Some of the content in this manual may differ from your product.



(E) Pixel Art Display Controls **F)** Sparkle Lighting

Flash Lighting G Speaker (Woofer) / Multi Color Ring Lighting

(D) Speaker (Tweeter)

(A) Handle

1 Connect the power cord to the product by opening the rear cover

2 Connecting the Speaker to a Smartphone via Bluetooth

1) Press the **Power** (1) button to turn on the product.

2) Press the Function [2] button on the product repeatedly to select the BT function. The BT LED blinks.

(3) Tap the Settings 🚳 button on your smartphone and select Bluetooth. Turn on the Bluetooth function. On)

(4) From the list of smartphone devices, find and tap on "LG-XL9T(XX)."

(5) Once the smartphone is connected to the product via **Bluetooth**, the BT LED will turn on. Play a desired track in the music app on your smartphone.

3 Playing Music from the USB

(1) Open the back cover of the product and plug the USB storage device into the USB terminal.

2 Press the **Power** (b) button to turn on the product.

3) Press the Function 🖳 button on the product repeatedly to select the USB function. The USB LED will turn on.

4) Press the Play/Pause [NI] button to enjoy the music.

4 Connecting to the LG XBOOM App

(1) Find the **LG XBOOM app** on the Google Play or App Store and install it on your smartphone.

(2) Run the LG XBOOM app and use its functions. (EQ, Wireless Party Link, Pixel Art Display, Lighting, Setting etc.)

5 Power Saving

If there is no playback or button input for 15 minutes, the product turns off automatically. On the LG XBOOM app, you can enable or disable [Auto Power Management].

• Actual features, functionality, and other product specifications may differ and are subject to change without notice.

ENGLISH

Specification

Power requirements Refer to the main label.

Power consumption Refer to the main label.

Dimensions (W x H x D): Approx. 404.0 mm x 916.0 mm x 428.0 mm (15.9 inch x 36.1 inch x 16.8 inch) Bus Power Supply (USB): 5 V === 500 mA Operating Temperature: 5 °C - 40 °C (41 °F to 104 °F) Operating Humidity: 5 % - 80 % RH Ingress Protection: IPX4

- Speaker tested under controlled laboratory conditions with an IPX4 rating. Resistant to splashed water. Dry before using. Do not charge while wet.

 Do not leave the unit on an unstable place. It may fall down because of the vibration of the sound. **CAUTION** when using this product in environments of low

humidity. - It may cause static electricity in environments of low

- To prevent static electricity, it is recommended to touch metal objects before using this product.

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

 Reorient or relocate the receiving antenna. Increase the separation between the equipment and the

Connect the equipment to an outlet on a circuit different

from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician

for help. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications in construction of this device which are not expressly approved by the party responsible for compliance could void the user's authority to operate the

FCC RF Radiation Exposure Statement: This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be colocated or operating in conjunction with any other antenna or transmitter.

This equipment should be installed and operated with minimum distance 20 cm (7.8 inches) between the antenna may cause damage to the device. The LG limited warranty and your body. Users must follow the specific operating instructions for satisfying RF exposure compliance.

Supplier's Declaration of Conformity

Trade Name Responsible Party

LG Electronics USA, Inc. 111 Sylvan Avenue, North Building Englewood Cliffs, New Jersey 07632 lg.environmental@lge.com

CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF FLECTRIC SHOCK DO NOT REMOVE COVER (OR BACK), NO USER-SERVICEABLE PARTS INSIDE, REFER SERVICING TO QUALIFIED SERVICE



alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons. The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

This lightning flash with arrowhead symbol

within an equilateral triangle is intended to

WARNING:

 TO PREVENT FIRE OR ELECTRIC SHOCK HAZARD. DO NOT EXPOSE THIS PRODUCT TO RAIN OR MOISTURE.

 Do not install this equipment in a confined space such as a book case or similar unit.

• Do not use high voltage products around this product. (ex. Electrical swatter) This product may malfunction due to electrical shock.

 No naked flame sources, such as lighted candles, should be placed on the apparatus.

• Do not block any ventilation openings. Install in accordance with the manufacturer's instructions. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from over heating. The openings should never be blocked by placing the product on a bed, sofa, rug or other similar surface. This product shall not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instruction has been adhered to.

 Install this apparatus in a location where the power plug can be easily unplugged and plugged in. If there is a fire or problem with this apparatus, unplug it guickly.

 The apparatus should not be exposed to water (dripping) or splashing) and no objects filled with liquids, such as vases, should be placed on the apparatus.

 For safety marking information including product identification and supply ratings, please refer to the main label on the bottom or the other surface of the product

Only use the AC adapter supplied with this device. Do not use a power supply from another device or another manufacturer. Using any other power cable or power supply does not cover damage caused by the use of third party

For models using a battery

This device is equipped with a portable battery or accumulator

How to Safely remove the batteries or the battery

is recommended that you use local, free reimbursement

systems batteries or battery packs. (may not be available in

your area). The batteries or the battery pack should not be

exposed to excessive heat such as sunshine, fire or the like.

Do not store or transport at pressures lower than 11.6 kPa

defeat a safeguard (for example, in the case of some

mechanically crushing or cutting of a battery, that can

surrounding environment that can result in an explosion

(0.116 bar) and at above 15,000 m (9.32 miles) altitude.

disposal of a battery into fire or a hot oven, or

leaving a battery in an extremely high temperature

a battery subjected to extremely low air pressure that

may result in an explosion or the leakage of flammable

or the leakage of flammable liquid or gas;

IMPORTANT SAFETY INSTRUCTIONS

5. Do not use this apparatus near water.

amplifiers) that produce heat.

7. Do not block any ventilation openings. Install in

accordance with the manufacturer's instructions.

8. Do not install near any heat sources such as radiators.

heat registers, stoves, or other apparatus (including

For models using a built-in battery

lithium battery types);

result in an explosion;

Read these instructions.

Keep these instructions.

Follow all instructions.

Clean only with dry cloth.

Heed all warnings.

liquid or gas.

pack from the equipment: To Remove the old batteries or

with one wider than the other. A grounding type plug has **CAUTION:** Risk of fire or explosion if the battery is replaced two blades and a third grounding prong. The wide blade by an incorrect type or the third prong are provided for your safety. If the

battery pack, follow the assembly steps in reverse order. 10. Protect the power cord from being walked on or pinched To prevent contamination of the environment and bring particularly at plugs, convenience receptacles, and the on possible threat to human and/or animal health, the old point where they exit from the apparatus. batteries or the battery pack must be put in an appropriate 11. Only use attachments/accessories specified by the container at designated collection points. Do not dispose manufacturer. of batteries or battery pack together with other waste. It


12. Use only with the cart, stand, tripod, bracket, or table specified

9. Do not defeat the safety purpose of the polarized or

grounding-type plug. A polarized plug has two blades

provided plug does not fit into your outlet, consult an

electrician for replacement of the obsolete outlet.



13. Unplug this apparatus during lightning storms or when replacement of a battery with an incorrect type that can unused for long periods of time.

> 14. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.

,	
~	Refers to alternating current (AC).
===	Refers to direct current (DC).
	Refers to class II equipment.
Ф	Refers to stand-by.
Ι	Refers to "ON" (power).
4	Refers to dangerous voltage.

USA Only (Product with embedded rechargeable battery

In case rechargeable battery is included in this product the entire device should be recycled in compliance with rechargeable battery recycling standards because of the internal battery. To dispose of properly, call (800) 822-8837 or visit www.call2recycle.org.

XL9T.DUSALLK_SIMPLE_MFL72017135 (sheet).indd 6-10 2024-09-25 3:49:35