1.7 cu. ft. Smart Over-the-Range Convection Microwave Oven with Air Fry



- 1.7 cu. ft. Oven Capacity
- Convection Technology
- SmoothTouch™ Glass Controls
- 950 Watt Microwave Power
- 1,550 Watt Convection Power
- Sensor Cooking
- 10 Power Levels
- 8 Auto Cook Options
- Air Fry

- 300 CFM Exhaust Fan
- Stainless Steel Interior
- LED Lighting
- Rack for 2-Level Cooking
- Wi-Fi Connect (works with ThinQ® Technology)
- Scan-to-Cook
- LG Smart Range Connectivity






COLOR AVAILABILITY		
	MHES1738F – PrintProof™ Stainless Steel	

COOKING FEATURES	
Oven Capacity	1.7 cu. ft.
Microwave Power Output	950 W
Convection Power Output	1,550 W
EasyClean® Interior	No
Sensor Cook Options	Yes
Power Levels	10
Defrost	Auto
Sensor Reheat	Yes
Auto Cook Options	11 (Auto Defrost, Sensor Cook, Sensor Reheat, Steam Cook, Popcorn, Soften, Melt, Kids Meal, Simmer, Speed Combi., Air Fry)
Air Fry	Yes
Dehydrate	Yes
Custom Settings	Yes
CONVENIENCE FEATURES	
Control Type	SmoothTouch [™] Glass
Turntable Diameter	13.5"
Metal Rack	Yes
Clock	Yes
Kitchen Timer	Yes
Completion Beeper	Yes
Turntable On / Off	Yes
Add 30 Seconds	Yes
Energy Savings Key (Turns Off LED Display)	No
Exterior Lighting	LED
Interior Lighting	LED
Child Lock	Yes
VENTING SYSTEM	
ExtendaVent [™] (slide-out)	No
Filtration	Charcoal Filter

Exhaust Grease Filters	2			
Power Levels	5			
Vent Grille Type	Hidden			
Vent Air Flow	300 CFM			
Venting Options	Roof, Wall, Room			
SMART FEATURES				
Wi-Fi Enabled	Yes			
Wi-Fi Connect (works with ThinQ° Technology)	Yes			
Scan-to-Cook	Yes			
Smart LG Range Connectivity	Yes			
APPEARANCE / MATERIALS / FIN	ISHES			
WideView [™] Window	Yes			
Interior Color	Stainless Steel			
Clock Display Color	White			
TECHNICAL SPECS				
Required Power Supply	120V, 60 Hz			
Minimum Circuit Rating	15 Amp			
Plug Type	3-Prong			
INCLUDED ACCESSORIES				
Glass Turntable, Metal Tray, Steam Bowl, Metal Rack				
DIMENSIONS / CLEARANCES / W	EIGHT			
Product Dimensions (W x H x D)	29 7 / ₈ " x 16 1 / ₄ " x 16 3 / ₈ "			
Oven Interior Dimensions (W x H x D)	21 5/8" x 9 3/4" x 14 1/4"			
Cut-out Dimensions (W x D)	30" x 13"			
Minimum Distance from Cooking Surface	30"			
Carton Dimensions (W x H x D)	33 7/ ₁₆ " x 20 15/ ₁₆ " x 19 5/ ₁₆ "			
Approx. Weight (Product / Carton)	72.3 lbs. / 82.2 lbs.			
LIMITED WARRANTY				
Parts and Labor	2 Years			
Magnetron	5 Years			

DIMENSIONS / CLEARANCES



DIMENSIONS / CLEARANCES			
1	Maximum 13" cabinet depth		
2	Minimum 30" cabinet opening width		
3	Minimum 30" clearance from bottom of cabinet to cooking surface or countertop before installation. (Use templates included with installation instructions)		
4	Grounded outlet (inside upper cabinet)		
5	Power supply cord hole		

PREPARING CABINET OPENING

DO NOT EXPOSE YOURSELF TO EXCESSIVE MICROWAVE ENERGY!

- DO NOT try to operate the microwave oven with the door open.
- DO NOT tamper with or defeat the safety interlocks.
- DO NOT place objects between the microwave oven front face and the door.
- DO NOT allow soil or cleaner residue to build up on the flat surfaces around the microwave oven door.
- DO NOT operate the microwave oven if it is damaged.
- The microwave oven door must close properly to operate safely.

DO NOT USE THE MICROWAVE OVEN:

- If the door is bent.
- If the hinges or latches are broken or loose.
- If the door seals, sealing surfaces or glass is broken.

DO NOT ATTEMPT TO ADJUST OR REPAIR THE OVEN YOURSELF!

 It should be adjusted and repaired by a qualified technician who can check for microwave leakage after repairing the oven.

MAKE SURE YOU HAVE ENOUGH SPACE AND SUPPORT.

- \bullet Mount the oven against a flat, vertical wall, so that it is supported by the wall. The wall should be constructed of minimum 2" x 4" wood studding and 3/8" thick drywall or plaster/lath.
- ATTACH AT LEAST ONE of the two lag screws supporting the oven to a vertical, 2" x 4" wall stud.
- DO NOT mount the microwave oven to an island or peninsula cabinet.
- BE SURE the upper cabinet and rear wall structures are able to support 150 lbs., plus the weight of any items you place inside the oven or upper cabinet.
- Locate the oven away from strong draft areas, such as windows, doors, and strong heating vents.
- BE SURE you have enough space. See below for minimum vertical and horizontal clearance.

